

# USER'S GUIDE



## Vaisala HUMICAP<sup>®</sup> Humidity and Temperature Transmitter Series HMT330



PUBLISHED BY

Vaisala Oyj  
P.O. Box 26  
FIN-00421 Helsinki  
Finland

Phone (int.): +358 9 8949 1  
Fax: +358 9 8949 2227

Visit our Internet pages at <http://www.vaisala.com/>

© Vaisala 2007

No part of this manual may be reproduced in any form or by any means, electronic or mechanical (including photocopying), nor may its contents be communicated to a third party without prior written permission of the copyright holder.

The contents are subject to change without prior notice.

Please observe that this manual does not create any legally binding obligations for Vaisala towards the customer or end user. All legally binding commitments and agreements are included exclusively in the applicable supply contract or Conditions of Sale.

---

# Table of Contents

## CHAPTER 1

<b>GENERAL INFORMATION</b> .....	<b>9</b>
<b>About This Manual</b> .....	<b>9</b>
Contents of This Manual .....	9
Version Information .....	10
General Safety Considerations .....	10
Feedback.....	11
<b>Product Related Safety Precautions</b> .....	<b>11</b>
ESD Protection.....	11
<b>Recycling</b> .....	<b>12</b>
<b>Trademarks</b> .....	<b>12</b>
<b>License Agreement</b> .....	<b>12</b>
<b>Warranty</b> .....	<b>13</b>

## CHAPTER 2

<b>PRODUCT OVERVIEW</b> .....	<b>15</b>
<b>Introduction to HMT330</b> .....	<b>15</b>
Basic Features and Options.....	16
Structure of the Transmitter .....	17
Probe Options .....	19
Warned Probe HMT337 .....	20

## CHAPTER 3

<b>INSTALLATION</b> .....	<b>21</b>
<b>Mounting the Housing</b> .....	<b>21</b>
Standard Mounting without Mounting Plate .....	21
Wall Mounting with Wall Mounting Kit.....	22
Mounting with DIN Rail Installation Kit.....	23
Pole Installation with Installation Kit for Pole or Pipeline ....	24
Mounting Rain Shield with Installation Kit .....	26
Panel Mounting Frame .....	26
<b>Wiring</b> .....	<b>28</b>
Cable Bushings .....	28
Grounding the Cables .....	29
Grounding the Transmitter Housing.....	30
Signal and Power Supply Wiring.....	31
Connections to a 24 VAC Power Supply .....	32
<b>Probe Mounting</b> .....	<b>34</b>
General Instructions for Probes with a Cable .....	35
HMT333 for Ducts and Tight Spaces.....	37
HMT334 for High Pressure and Vacuum Applications .....	37
HMT335 for High Temperatures .....	40
HMT337 for High Humidity Applications .....	40
Temperature Probe (Optional) .....	40

HMT338 for Pressurized Pipelines .....	41
Tightening the Clasp Nut .....	42
<b>Optional Modules .....</b>	<b>44</b>
Power Supply Module .....	44
Installation .....	45
Warnings .....	46
Galvanic Isolation for Output .....	49
Third Analog Output .....	49
Installation and Wiring .....	50
Relays .....	51
Installation and Wiring .....	51
Selecting the Activation State of the Relay .....	51
RS-422/485 Interface .....	53
Installation and Wiring .....	53
Data Logger Module .....	55
8-Pin Connector .....	57

CHAPTER 4

<b>OPERATION .....</b>	<b>59</b>
<b>Getting Started .....</b>	<b>59</b>
<b>Display/Keypad (Optional) .....</b>	<b>59</b>
Basic Display .....	59
Graphic History .....	60
Menus and Navigation .....	62
Changing the Language .....	63
Rounding Setting .....	64
Display Backlight Setting .....	64
Display Contrast Setting .....	64
Keypad Lock (Key guard) .....	64
Menu PIN Lock .....	65
Factory Settings .....	65
<b>MI70 Link Program for Data Handling .....</b>	<b>66</b>
<b>Serial Line Communication .....</b>	<b>66</b>
User Port Connection .....	67
Service Port Connection .....	68
Connection Cables .....	68
Installing the Driver for the USB Cable .....	69
Using the Service Port .....	69
Terminal Program Settings .....	70
List of Serial Commands .....	72
Getting Measurement Message from Serial Line .....	74
Starting Continuous Outputting .....	74
R .....	74
Stopping Continuous Outputting .....	75
S .....	75
Outputting Reading Once .....	75
SEND .....	75
SEND D .....	75
Formatting Serial Line Message .....	76
FTIME and FDATE .....	76
FST .....	76
<b>General Settings .....</b>	<b>77</b>
Changing Quantities and Units .....	77

---

Using Display/Keypad .....	77
Using Serial Line .....	78
FORM .....	78
UNIT .....	80
Pressure Compensation Setting .....	80
Using Display/Keypad .....	80
Using Serial Line .....	81
PRES and XPRES .....	81
Date and Time .....	82
Using Display/Keypad .....	82
Using Serial Line .....	82
User Port Serial Settings .....	83
Using Display/Keypad .....	83
Using Serial Line .....	84
SERI .....	84
SMODE .....	84
INTV .....	85
ECHO .....	85
Data Filtering .....	86
FILT .....	86
Device Information .....	86
? .....	87
HELP .....	88
ERRS .....	88
VERS .....	89
Resetting Transmitter Using Serial Line .....	89
RESET .....	89
Locking Menu/Keypad by Using Serial Line .....	89
LOCK .....	89
<b>Data Recording .....</b>	<b>90</b>
Selecting Data Recording Quantities .....	90
DSEL .....	90
View Recorded Data .....	91
DIR .....	91
PLAY .....	92
Deleting the Recorded Files .....	93
UNDELETE .....	93
<b>Analog Output Settings .....</b>	<b>93</b>
Changing Output Mode and Range .....	94
Analog Output Quantities .....	95
AMODE/ASEL .....	96
Analog Output Tests .....	97
ITEST .....	97
Analog Output Fault Indication Setting .....	98
AERR .....	98
<b>Operation of Relays .....</b>	<b>99</b>
Quantity for Relay Output .....	99
Measurement-Based Relay Output Modes .....	99
Relay Setpoints .....	99
Hysteresis .....	100
Relay Indicating Transmitter Error Status .....	100
Enabling/Disabling Relays .....	102
Setting Relay Outputs .....	102
RSEL .....	103
Testing Operation of Relays .....	104

RTEST.....	105
<b>Operation of the RS-485 Module.....</b>	<b>105</b>
Networking Commands.....	106
SDELAY.....	106
SERI.....	106
ECHO.....	107
SMODE.....	107
INTV.....	108
ADDR.....	108
SEND.....	109
OPEN.....	109
CLOSE.....	109
<b>Sensor Functions.....</b>	<b>110</b>
Chemical Purge (Optional).....	110
Automatic Chemical Purge (Interval Purge).....	111
Manual Chemical Purge.....	111
Chemical Purge in Power Up.....	111
Starting and Configuring Chemical Purge.....	112
Using Buttons on Motherboard.....	112
Using Display/Keypad (Optional).....	112
Using Serial Line.....	113
PURGE.....	113
PUR.....	114
Sensor Heating.....	115
Setting Humidity Sensor Heating.....	115
XHEAT.....	115
CHAPTER 5	
<b>MAINTENANCE.....</b>	<b>117</b>
<b>Periodic Maintenance.....</b>	<b>117</b>
Cleaning.....	117
Changing the Probe Filter.....	117
<b>Changing the Sensor.....</b>	<b>118</b>
Error States.....	119
<b>Technical Support.....</b>	<b>121</b>
<b>Return Instructions.....</b>	<b>121</b>
<b>Vaisala Service Centers.....</b>	<b>122</b>
CHAPTER 6	
<b>CALIBRATION AND ADJUSTMENT.....</b>	<b>123</b>
<b>Opening and Closing the Adjustment Mode.....</b>	<b>123</b>
<b>Relative Humidity Adjustment.....</b>	<b>125</b>
Using Push-Buttons.....	125
Using Display/Keypad.....	126
Using Serial Line.....	127
CRH.....	127
<b>Relative Humidity Adjustment after Sensor Change.....</b>	<b>128</b>
Using Display/Keypad.....	128
Using Serial Line.....	128
FCRH.....	129
<b>Temperature Adjustment.....</b>	<b>129</b>

Using Display/Keypad .....	129
Using Serial Line .....	130
<b>Analog Output Adjustment.....</b>	<b>131</b>
Using Display/Keypad .....	131
Using Serial Line .....	131
ACAL.....	131
<b>Feeding Adjustment Information .....</b>	<b>132</b>
Using Display/Keypad .....	132
Using Serial Line .....	132
CTEXT .....	132
CDATE .....	132

CHAPTER 7

<b>TECHNICAL DATA .....</b>	<b>133</b>
<b>Specifications .....</b>	<b>133</b>
Performance.....	133
Relative Humidity .....	133
Temperature (+ Operating Pressure Ranges) .....	134
Optional Temperature Probe .....	134
Calculated Variables .....	135
Accuracies of Calculated Variables .....	135
Accuracy of Dewpoint Temperature °C .....	135
Accuracy of Mixing Ratio g/kg (Ambient Pressure 1013 mbar).....	136
Accuracy of Wet Bulb Temperature °C.....	136
Accuracy of Absolute Humidity g/m <sup>3</sup> .....	136
Dewpoint Temperature (HMT337 Warmed Probe Option).....	137
Operating Environment .....	137
Inputs and Outputs.....	138
Mechanics .....	138
Transmitter Weight.....	139
Technical Specifications of Optional Modules .....	139
Power Supply Module .....	139
Analog Output Module .....	139
Relay Module .....	140
RS-485 Module .....	140
Data Logger Module .....	140
<b>Options and Accessories .....</b>	<b>141</b>
<b>Dimensions (in mm).....</b>	<b>143</b>
HMT331.....	144
HMT333.....	144
HMT334.....	145
HMT335.....	145
HMT337.....	146
HMT338.....	146
Temperature Probe .....	146

APPENDIX A

<b>PROBE INSTALLATION KITS AND INSTALLATION EXAMPLES .....</b>	<b>147</b>
<b>Duct Installation Kits (for HMT333/337/335) .....</b>	<b>147</b>
<b>Duct Installation Kit for Temperature Probe (for HMT337).....</b>	<b>148</b>
<b>Pressure Tight Swagelok Installation Kits (for HMT337) ..</b>	<b>149</b>

RH Probe Installation.....	149
Temperature Probe Installation .....	149
<b>Examples of Vapor Tight Installations with Cable Gland.150</b>	
RH-Probe Installations (for HMT333/337).....	150
T- Probe Installations (HMT337) .....	151
Example of Climate Chamber Installation .....	152
Example of Installation Through Roof .....	153
<b>Ball Valve Installation Kit for HMT338 .....</b>	<b>154</b>
<b>Meteorological Installation Kit (for HMT337) .....</b>	<b>156</b>

APPENDIX B

<b>CALCULATION FORMULAS.....</b>	<b>157</b>
----------------------------------	------------

## List of Figures

Figure 1	Transmitter Body .....	17
Figure 2	Inside the Transmitter.....	18
Figure 3	Probe Options.....	19
Figure 4	Standard Mounting .....	21
Figure 5	Mounting with Wall Mounting Kit .....	22
Figure 6	Dimensions of the Plastic Mounting Plate .....	22
Figure 7	Mounting with the DIN Rail Installation Kit .....	23
Figure 8	Vertical Pole.....	24
Figure 9	Horizontal Pole .....	24
Figure 10	Mounting with Metal Wall Mounting Plate .....	25
Figure 11	Dimensions of the Metal Mounting Plate (mm) .....	25
Figure 12	Mounting the Rain Shield with the Installation Kit .....	26
Figure 13	Panel Mounting Frame .....	27
Figure 14	Panel Mounting Dimensions.....	27
Figure 15	Cable Bushings.....	28
Figure 16	Grounding the Screen of Electrical Cable .....	29
Figure 17	Screw Terminal Block on Motherboard .....	31
Figure 18	Connections to 24 VAC Power Supply .....	33
Figure 19	Measurement Error at 100 %RH .....	34
Figure 20	Horizontal Mounting of Probe .....	35
Figure 21	Vertical Mounting of Probe .....	36
Figure 22	HMT344 Probe .....	38
Figure 23	Tightening the Nut .....	38
Figure 24	Cleaning of Tightening Cone.....	39
Figure 25	HMT338 Probe .....	41
Figure 26	Sealing of Fitting Body into Process.....	42
Figure 27	Tightening the Clasp Nut.....	42
Figure 28	Power Supply Module.....	44
Figure 29	Galvanic Output Isolation Module.....	49
Figure 30	Third Analog Output .....	49
Figure 31	Third analog output selection .....	50
Figure 32	Relay Module.....	52
Figure 33	RS-485 Module.....	53
Figure 34	4-Wire RS-485 Bus.....	54
Figure 35	Data Logger Module .....	56
Figure 36	Wiring of Optional 8-Pin Connector.....	57
Figure 37	Basic Display .....	60
Figure 38	Graphical Display .....	60

Figure 39	Graphical Display with Data Logger .....	61
Figure 40	Main Menus .....	63
Figure 41	Service Port Connector and User Port Terminal on Mother Board .....	67
Figure 42	Connection Example Between PC Serial Port and User Port..	68
Figure 43	Starting Hyper Terminal Connection .....	70
Figure 44	Connecting to Hyper Terminal .....	71
Figure 45	Hyper Terminal Serial Port Settings.....	71
Figure 46	Device Information on Display .....	87
Figure 47	Current/Voltage Switches of Output Modules .....	94
Figure 48	Measurement-Based Relay Output Modes .....	99
Figure 49	FAULT/ONLINE STATUS Relay Output Modes .....	101
Figure 50	Relay Indicators on Display.....	102
Figure 51	Decrease of Sensor Gain .....	110
Figure 52	Purge Buttons on Motherboard .....	112
Figure 53	Chemical Purge Settings.....	112
Figure 54	Performing Chemical Purge .....	113
Figure 55	Changing the Sensor.....	118
Figure 56	Error Indicator and Error Message.....	119
Figure 57	Adjustment and Purge Buttons .....	124
Figure 58	Adjustment Menu .....	124
Figure 59	Selecting Point 1 Reference Type.....	126
Figure 60	Accuracy over Temperature Range .....	134
Figure 61	Accuracy in Dewpoint Measurement.....	137
Figure 62	Transmitter Body Dimensions .....	143
Figure 63	HMT331 Probe Dimensions .....	144
Figure 64	HMT333 Probe Dimensions .....	144
Figure 65	HMT334 Probe Dimensions .....	145
Figure 66	HMT335 Probe Dimensions .....	145
Figure 67	HMT337 Probe Dimensions .....	146
Figure 68	HMT338 Probe Dimensions .....	146
Figure 69	Optional Temperature Probe Dimensions.....	146
Figure 70	Duct Mounting Installation Kit.....	147
Figure 71	Duct Mounting Installation Kit for T-Probe .....	148
Figure 72	Swagelok Installation Kit for RH-probe .....	149
Figure 73	Swagelok Installation Kit for T-Probe .....	149
Figure 74	Cable Installation with Cable Gland .....	150
Figure 75	Probe Installation with Cable Gland .....	150
Figure 76	Vapor Tight Installation.....	151
Figure 77	Wall Mounting Installation .....	151
Figure 78	Climate Chamber Installation (not Available from Vaisala)....	152
Figure 79	Example of Installation through Roof .....	153
Figure 80	Installing the HMT338 Probe Through a Ball Valve Assembly	154
Figure 81	Meteorological Installation Kit for Outdoor Installation.....	156

## List of Tables

Table 1	Manual Revisions .....	10
Table 2	Quantities Measured by HMT330 .....	15
Table 3	Optional Quantities Measured by HMT330 .....	16
Table 4	HMT338 Probe Dimensions .....	41
Table 5	Connecting the Twisted Pair Wires to the Screw Terminals....	53
Table 6	4-Wire (Switch 3: On) .....	54
Table 7	2-Wire (Switch 3: Off) .....	55

---

Table 8	Wiring of 8-Pin Connector .....	57
Table 9	Periods for Trend and Max/Min Calculations .....	61
Table 10	Graph Information Messages in Cursor Mode .....	62
Table 11	Default Serial Communication Settings for the User Port .....	67
Table 12	Communication Settings for the Service Port.....	70
Table 13	Measurement Commands .....	72
Table 14	Formatting Commands .....	72
Table 15	Data Recording Commands .....	72
Table 16	Chemical Purge Commands.....	73
Table 17	Calibration and Adjustment Commands.....	73
Table 18	Setting and Testing the Analog Outputs.....	73
Table 19	Setting and Testing the Relays.....	73
Table 20	Other Commands .....	74
Table 21	FORM Command Modifiers.....	79
Table 22	Multiplication Factors.....	81
Table 23	Selection of Output Modes .....	85
Table 24	Filtering Levels.....	86
Table 25	Error Messages .....	120
Table 26	Indicator Led Functions .....	124
Table 27	Calculated Variables (Typical Ranges) .....	135
Table 28	Transmitter Weight (in kg/lb) .....	139

# CHAPTER 1

## GENERAL INFORMATION

This chapter provides general notes for the manual and the product.

### About This Manual

This manual provides information for installing, operating, and maintaining Vaisala HUMICAP<sup>®</sup> Humidity and Temperature Transmitter Series HMT330.

### Contents of This Manual

This manual consists of the following chapters:

- Chapter 1, General Information, provides general notes for the manual and the product.
- Chapter 2, Product Overview, introduces the features, advantages, and the product nomenclature of HMT330.
- Chapter 3, Installation, provides you with information that is intended to help you install the product.
- Chapter 4, Operation, contains information that is needed to operate this product.
- Chapter 5, Maintenance, contains information that is needed in basic maintenance of the product.
- Chapter 6, Calibration and Adjustment, provides information and instructions concerning calibration and adjustment of HMT330.
- Chapter 7, Technical Data, provides the technical data of the product.

- Appendix A, Probe Installation Kits and Installation Examples, presents the installation kits available for HMT330 and provides some installation examples.
- Appendix B, Calculation Formulas, presents the equations used in HMT330 to calculate values of dewpoint, mixing ratio, absolute humidity and enthalpy in normal pressure.

## Version Information

**Table 1 Manual Revisions**

Manual Code	Description
M210566EN-A	September 2004 - First release.
M210566EN-B	November 2004
M210566EN-C	September 2005
M210566EN-D	November 2006
M210566EN-E	June 2007 - New options added: Data logger module, USB-RJ45 cable, new sensors HUMICAP® 180R and HUMICAP® 180RC. Support for Chinese language.

## General Safety Considerations

Throughout the manual, important safety considerations are highlighted as follows:

### **WARNING**

Warning alerts you to a serious hazard. If you do not read and follow instructions very carefully at this point, there is a risk of injury or even death.

### **CAUTION**

Caution warns you of a potential hazard. If you do not read and follow instructions carefully at this point, the product could be damaged or important data could be lost.

### **NOTE**

Note highlights important information on using the product.

## Feedback

Vaisala Customer Documentation Team welcomes your comments and suggestions on the quality and usefulness of this publication. If you find errors or have other suggestions for improvement, please indicate the chapter, section, and page number. You can send comments to us by e-mail: [manuals@vaisala.com](mailto:manuals@vaisala.com)

## Product Related Safety Precautions

The Vaisala HUMICAP<sup>®</sup> Humidity and Temperature Transmitter Series HMT330 delivered to you has been tested for safety and approved as shipped from the factory. Note the following precautions:

**WARNING**

Ground the product, and verify outdoor installation grounding periodically to minimize shock hazard.

**CAUTION**

Do not modify the unit. Improper modification can damage the product or lead to malfunction.

## ESD Protection

Electrostatic Discharge (ESD) can cause immediate or latent damage to electronic circuits. Vaisala products are adequately protected against ESD for their intended use. However, it is possible to damage the product by delivering electrostatic discharges when touching, removing, or inserting any objects inside the equipment housing.

To make sure you are not delivering high static voltages yourself:

- Handle ESD sensitive components on a properly grounded and protected ESD workbench. When this is not possible, ground yourself to the equipment chassis before touching the boards. Ground yourself with a wrist strap and a resistive connection cord. When neither of the above is possible, touch a conductive part of the equipment chassis with your other hand before touching the boards.
- Always hold the boards by the edges and avoid touching the component contacts.

## Recycling



Recycle all applicable material.



Dispose of batteries and the unit according to statutory regulations.  
Do not dispose of with regular household refuse.

## Trademarks

HUMICAP<sup>®</sup> is a registered trademark of Vaisala. Microsoft<sup>®</sup>, Windows<sup>®</sup>, Windows<sup>®</sup> 2000, Windows Server<sup>®</sup> 2003, Windows<sup>®</sup> XP, and Windows<sup>®</sup> Vista are registered trademarks of Microsoft Corporation in the United States and/or other countries.

## License Agreement

All rights to any software are held by Vaisala or third parties. The customer is allowed to use the software only to the extent that is provided by the applicable supply contract or Software License Agreement.

## Warranty

Vaisala hereby represents and warrants all Products manufactured by Vaisala and sold hereunder to be free from defects in workmanship or material during a period of twelve (12) months from the date of delivery save for products for which a special warranty is given. If any Product proves however to be defective in workmanship or material within the period herein provided Vaisala undertakes to the exclusion of any other remedy to repair or at its own option replace the defective Product or part thereof free of charge and otherwise on the same conditions as for the original Product or part without extension to original warranty time. Defective parts replaced in accordance with this clause shall be placed at the disposal of Vaisala.

Vaisala also warrants the quality of all repair and service works performed by its employees to products sold by it. In case the repair or service works should appear inadequate or faulty and should this cause malfunction or nonfunction of the product to which the service was performed Vaisala shall at its free option either repair or have repaired or replace the product in question. The working hours used by employees of Vaisala for such repair or replacement shall be free of charge to the client. This service warranty shall be valid for a period of six (6) months from the date the service measures were completed.

This warranty is however subject to following conditions:

- a) A substantiated written claim as to any alleged defects shall have been received by Vaisala within thirty (30) days after the defect or fault became known or occurred, and
- b) The allegedly defective Product or part shall, should Vaisala so require, be sent to the works of Vaisala or to such other place as Vaisala may indicate in writing, freight and insurance prepaid and properly packed and labelled, unless Vaisala agrees to inspect and repair the Product or replace it on site.

This warranty does not however apply when the defect has been caused through

- a) normal wear and tear or accident;
- b) misuse or other unsuitable or unauthorized use of the Product or negligence or error in storing, maintaining or in handling the Product or any equipment thereof;
- c) wrong installation or assembly or failure to service the Product or otherwise follow Vaisala's service instructions including any repairs or installation or assembly or service made by unauthorized personnel not approved by Vaisala or replacements with parts not manufactured or supplied by Vaisala;
- d) modifications or changes of the Product as well as any adding to it without Vaisala's prior authorization;
- e) other factors depending on the Customer or a third party.

Notwithstanding the aforesaid Vaisala's liability under this clause shall not apply to any defects arising out of materials, designs or instructions provided by the Customer.

This warranty is expressly in lieu of and excludes all other conditions, warranties and liabilities, express or implied, whether under law, statute or otherwise, including without limitation any implied warranties of merchantability or fitness for a particular purpose and all other obligations and liabilities of Vaisala or its representatives with respect to any defect or deficiency applicable to or resulting directly or indirectly from the Products supplied hereunder, which obligations and liabilities are hereby expressly cancelled and waived. Vaisala's liability shall under no circumstances exceed the invoice price of any Product for which a warranty claim is made, nor shall Vaisala in any circumstances be liable for lost profits or other consequential loss whether direct or indirect or for special damages.

This page intentionally left blank.

## CHAPTER 2

# PRODUCT OVERVIEW

This chapter introduces the features, advantages, and the product nomenclature of the Vaisala HUMICAP<sup>®</sup> Humidity and Temperature Transmitter Series HMT330.

## Introduction to HMT330

The HMT330 transmitter provides reliable humidity measurement in a wide range of applications. Analog outputs can be chosen between current and voltage signals. Alternatively, digital outputs RS-232 (standard) or RS-422/485 (optional) can be selected.

The quantities measured and calculated by HMT330 are presented in Table 2 below. The quantities available as an option are presented in Table 3 below.

**Table 2 Quantities Measured by HMT330**

Quantity	Abbreviation	Metric Unit	Non Metric Unit
Relative humidity (RH)	RH	%RH	%RH
Temperature (T)	T	°C	°F


**Table 3 Optional Quantities Measured by HMT330**

Quantity	Abbreviation	Metric Unit	Non Metric Unit
Dewpoint / Frostpoint Temperature ( $T_{d/f}$ )	TDF	°C	°F
Dewpoint Temperature ( $T_d$ )	TD	°C	°F
Absolute humidity (a)	A	g/m <sup>3</sup>	gr/ft <sup>3</sup>
Mixing ratio (x)	X	g/kg	gr/lb
Wetbulb temperature ( $T_w$ )	TW	°C	°F
Humid air volume/ dry air volume (by volume or by weight) ( $H_2O$ )	H2O	ppmv/ppm <sub>w</sub>	ppm <sub>v</sub> /ppm <sub>w</sub>
Water vapor pressure ( $P_w$ )	PW	hPa	lb/in <sup>2</sup>
Water vapor saturation pressure ( $P_{ws}$ )	PWS	hPa	lb/in <sup>2</sup>
Enthalpy (h)	H	kJ/kg	Btu/lb
Difference of T and $T_{d/f}$ ( $\Delta T$ )	DT	°C	°F

## Basic Features and Options

- Several probes for various applications
- User friendly display
- Calculated output quantities available
- Different probe mounting kits, sensor protection options and probe cable lengths
- Transmitter mounting kits for multiple installation purposes
- Chemical purge for applications where interfering chemicals in the measuring environment pose a risk
- Warmed probe and sensor heating for high humidity conditions (HMT337)
- Additional temperature sensor (HMT337)
- USB connectivity for service connections via the optional USB-RJ45 cable
- Optional modules:
  - isolated power supply
  - power supply module
  - RS-422/485-module
  - data logger module with real time clock
  - additional analog output module
  - relay module

## Structure of the Transmitter




0604-005

**Figure 1 Transmitter Body**

The numbers refer to Figure 1 above:

- 1 = Signal + powering cable gland
- 2 = Cable gland for optional module
- 3 = Cable gland for optional module
- 4 = Cover screw (4 pcs)
- 5 = Display with keypad (optional)
- 6 = Cover LED




0508-010

**Figure 2 Inside the Transmitter**

The following numbers refer to Figure 2 above:

- 1 = Service port (RS-232)
- 2 = DIP switches for analog output settings
- 3 = Power supply and signal wiring screw terminals
- 4 = Relay, data logger, or RS-422/485 module (optional)
- 5 = Grounding connector
- 6 = Power supply module (optional)
- 7 = Relay, data logger, or analog output module (optional)
- 8 = Humidity probe cable
- 9 = Temperature probe cable (optional)
- 10 = Output isolation module (optional)
- 11 = Adjustment buttons (chemical purge buttons) with indicator LED

## Probe Options



**Figure 3 Probe Options**

The following numbers refer to Figure 3 above:

- 1 = HMT331 for demanding wall-mounted applications
- 2 = HMT333 for ducts and tight spaces
- 3 = HMT334 for high pressure and vacuum applications (up to 100 bars)
- 4 = HMT335 for high temperatures (up to 180 °C, vapor tight)  
\*) Flange available as an option
- 5 = HMT337 for high humidity applications (optional warmed and vapor tight probe)
- 6 = HMT338 for pressurized pipelines (up to 40 bar)

Probe cable lengths are 2 m, 5 m and 10 m.

## Warmed Probe HMT337

Temperature difference between the probe and external environment can cause a risk of condensation on the sensor. A wet probe cannot observe the actual humidity in the ambient air. If the condensed water is contaminated, the life span of the probe may shorten and calibration may change.

HMT337 probe shall be used in applications where condensation can occur due to high humidity and rapid humidity changes. The warmed probe is heated continuously so that its temperature is always higher than in environment. This prevents condensation on the probe. The power consumption of the warmed probe is slightly higher than other probes.

## CHAPTER 3

# INSTALLATION


This chapter provides you with information that is intended to help you install the product.

## Mounting the Housing

The housing can be mounted either without the mounting plate or with optional mounting plates.

### Standard Mounting without Mounting Plate


Mount the housing by attaching the transmitter to a wall with 4 screws, for example M6 (not provided).



**Figure 4** Standard Mounting

## Wall Mounting with Wall Mounting Kit


When mounting with wall mounting kit the mounting plate (Vaisala order code 214829) can be installed directly on wall or onto a standard wall box (also US junction box). When wiring through back wall, remove the plastic plug from the wiring hole in the transmitter before mounting.



**Figure 5 Mounting with Wall Mounting Kit**

The following numbers refer to Figure 5 above:

- 1 = Plastic mounting plate
- 2 = Mount the plate to wall with 4 screws M6 (not provided)
- 3 = The arched side up
- 4 = Attach the HMT330 to the mounting plate with 4 fixing screws M3 (provided)
- 5 = Holes for wall/junction box mounting




**Figure 6 Dimensions of the Plastic Mounting Plate**

## Mounting with DIN Rail Installation Kit

DIN rail installation kit includes a wall mounting kit, 2 clip-fasteners and 2 screws M4 × 10 DIN 7985 (Vaisala order code: 215094).


1. Attach two spring holders to the plastic mounting plate by using the screws provided in the installation kit.
2. Attach the HMT330 to the plastic mounting plate with the 4 screws provided for that purpose.
3. Press the transmitter onto the DIN rail so that the clip-fasteners snap into the rail.



**Figure 7** Mounting with the DIN Rail Installation Kit

## Pole Installation with Installation Kit for Pole or Pipeline


Installation kit for pole or pipeline (Vaisala order code: 215108) includes the metal mounting plate and 4 mounting nuts for pole mounting. When mounting, the arrow in the metal mounting plate must point upwards; see Figure 10 on page 25 below.



**Figure 8** Vertical Pole

The following numbers refer to Figure 8 above:

- 1 = Fixing brackets (2 pcs) M8 (provided) for 30 ... 102 mm poles.
- 2 = Mounting nuts M8 (4 pcs)




**Figure 9** Horizontal Pole

The following number refers to Figure 9 above:

- 1 = Mounting nuts M8 (4 pcs)

Metal mounting plate is included in rain shield with installation kit and installation kit for pole or pipeline.




0503-041

**Figure 10 Mounting with Metal Wall Mounting Plate**

The following numbers refer to Figure 10 above:


- 1 = Mount the plate to wall with 4 screws M8 (not provided)
- 2 = Attach the HMT330 to the mounting plate with 4 fixing screws M6 (provided)
- 3 = Note the position of the arrow when mounting. This side must be up when mounting.



0508-023

**Figure 11 Dimensions of the Metal Mounting Plate (mm)**

## Mounting Rain Shield with Installation Kit



**Figure 12** Mounting the Rain Shield with the Installation Kit

The following numbers refer to Figure 12 above:

- 1 = Assemble the rain shield with the installation kit (Vaisala order code: 215109) to the metal mounting plate with 2 (M6) mounting screws (provided).
- 2 = Assemble the mounting plate with rain shield with installation kit to the wall or to the pole (see pole installation).
- 3 = Assemble the HMT330 to the mounting plate with 4 fixing screws (provided).

## Panel Mounting Frame


To enable a neat and dirt free embedded installation of the transmitter, a panel mounting frame is available as an option (Vaisala order code: 216038). The frame is a thin, flexible plastic frame for the transmitter, with adhesive tape on one side.

The frame is used to hide any rough edges of the installation hole, and provide a more finished look. Note that the panel mounting frame is not intended to bear the weight of the transmitter, and does not include any mounting supports.

Use the panel mounting frame as follows:

1. Use the frame as a template to mark the required size for the installation hole in the panel.
2. Cut the hole in the panel.
3. Mount the transmitter through the panel with suitable supports.


4. Remove the paper protecting the adhesive tape on the frame, and attach the frame around the transmitter. Refer to Figure 13 below.



**Figure 13 Panel Mounting Frame**

The following numbers refer to Figure 13 above:

- 1 = Panel (not included)
- 2 = Panel mounting frame




0703-068

**Figure 14 Panel Mounting Dimensions**

## Wiring

### Cable Bushings

A single electrical cable with screen and three to ten wires is recommended for power and analog/serial connections. The cable diameter should be 8 ... 11 mm. The number of cable bushings depends on the transmitter options. See the following recommendations for the cable bushings:



**Figure 15** Cable Bushings

The following numbers refer to Figure 15 above:

- 1 = Cable for signal/powering Ø8 ... 11 mm
- 2 = Cable for optional module Ø8 ... 11 mm
- 3 = Cable for optional power supply module Ø8 ... 11 mm

#### NOTE

When there is high electric noise level (for example, near a powerful electric motor) in the operating environment it is recommended to use shielded cable or take care that the signal cables are separated from other cables.

## Grounding the Cables

Ground the screen of the electrical cable properly to achieve the best possible EMC performance.

Fig. 1




Fig. 2





Fig. 3



0504-049

**Figure 16** Grounding the Screen of Electrical Cable

1. Cut back outer sheath to desired length.
2. Cut back screen braiding or screen foil to dimension X (see figure 3).
3. Push the domed cap nut (item 1) and the seal insert with contact socket of the gland (item 2+3) onto the cable as shown in the diagram.
4. Bend over the screen braiding or screen foil by about 90° (item 4).
5. Push the seal insert with the contact socket of the gland (item 2+3) up to the screen braiding or screen foil.
6. Mount lower part (item 5) on the housing.
7. Push the seal with the contact socket of the gland and (item 2+3) flush into the lower part (item 5).
8. Attach the domed cap nut (item 1) onto the lower part (item 5).


## Grounding the Transmitter Housing

In case you need to ground the transmitter housing, the grounding connector is found inside the housing, see Figure 2 on page 18. Note that the probe is connected to the same potential as the housing. Make sure that different groundings are made to the same potential. Otherwise harmful ground currents may be generated.

If it is needed to have galvanic isolation of the power supply line from the output signals, the HMT330 can be ordered with an optional output isolation module. This module prevents harmful grounding loops.

## Signal and Power Supply Wiring

When connecting the transmitter with 8-pin connector, see section 8-Pin Connector on page 57. When wiring the power supply module, see section Power Supply Module on page 44.



**Figure 17 Screw Terminal Block on Motherboard**

The following numbers refer to Figure 17 above:

- 1 = Power supply terminals 10 ... 35 VDC, 24 VAC
- 2 = User port (RS-232 terminals)
- 3 = Analog signal terminals

### WARNING

Make sure that you connect only de-energized wires.

1. Unfasten the four cover screws and open the transmitter cover.
2. Insert the power supply wires and signal wires through the cable bushing in the bottom of the transmitter; see the grounding instructions in the previous sections.
3. Connect the analog output cables to terminals: **Ch1 +**, **Ch1-**, **Ch2+**, **Ch2-**. Connect the RS-232 user port cables to terminals RxD, GND and TxD. For more information about the RS-232 connection refer to section Serial Line Communication on page 66.

4. When wiring the RS-485 module, relay module or additional analog output module, see section RS-422/485 Interface on page 53, section Relays on page 51, and section Third Analog Output on page 49.
5. Connect the power supply wires to the connectors: **POWER 10 ... 35V+ 24V~ (+) and (-) terminals**. If you are using 24 VAC power supply, see the note below before connecting the supply wires.
6. Turn on the power. The indicator led on the cover lit continuously during normal operation.
7. Close the cover and fasten the cover screws. The transmitter is ready for use.


## Connections to a 24 VAC Power Supply

Separate floating supply for each transmitter is recommended (see the upper part of Figure 18 on page 33). If you have to connect several transmitters or other instruments to one AC supply, the phase (~) must always be connected to the (+) connector of each transmitter (see the lower part of Figure 18).


**CAUTION****24 VAC POWER SUPPLY USE**

To prevent fire and/or damage, if either 24 VAC wire is **grounded** or **connected to a "-", "0", or "GND" terminal** of any other device, you must **connect the same wire on the "-" terminal** also on this instrument.

No common loop - RECOMMENDED!



Common loop formed - NOT recommended!




0703-041

**Figure 18** Connections to 24 VAC Power Supply

## Probe Mounting

In humidity measurement and especially in calibration it is essential that temperature of the probe and measuring environment is the same. Even a small difference in temperature between the environment and the probe causes an error. As the curve below shows, if the temperature is +20 °C and the relative humidity 100 %RH, a difference of  $\pm 1$  °C between the environment and the probe causes an error of  $\pm 6$  %RH.

The graph below illustrates the measurement error at 100 %RH when the difference between the ambient and sensor temperature is 1 °C.




0507-023

**Figure 19 Measurement Error at 100 %RH**

## General Instructions for Probes with a Cable

Mount the probes with a cable **horizontally**; this way, any water condensing on the tube cannot flow onto the sensor.




0507-024

**Figure 20 Horizontal Mounting of Probe**

The following numbers refer to Figure 20 above:

- 1 = To be sealed.
- 2 = To be insulated.
- 3 = Insulate the cable.
- 4 = Let the cable hang loosely. This prevents condensed water running to the probe along the cable.

When there is no alternative but to install the probe in the process **vertically**, the point of entry must be carefully insulated. The cable must also be allowed to hang loosely as this prevents any condensed water from running onto the probe along the cable.



0507-022

**Figure 21 Vertical Mounting of Probe**

The following numbers refer to Figure 21 above:

- 1 = To be sealed.
- 2 = Insulate the cable.
- 3 = To be insulated.
- 4 = Let the cable hang loosely. This prevents condensed water running to the sensor along the cable.

**NOTE**

Please do not attach a heated probe (HMT337) to metal structures to avoid condensation problems caused by heat conduction along the metal.

If the process temperature is much higher than that of the environment, the whole probe and preferably plenty of cable must be inside the process. This prevents measuring inaccuracy caused by heat conduction along the cable.

When mounted on the side of a duct or channel, the probe must be inserted from the side of the duct. If this is not possible and the probe must be inserted from the top, the point of entry must be carefully insulated.

For Vaisala probe installation kits and some installation examples, see Appendix A on page 147.

## HMT333 for Ducts and Tight Spaces

The HMT333 is a small size ( $\varnothing = 12\text{mm}$ ) general-purpose probe suitable for ducts and channels with the installation kit available from Vaisala.

The HMT333 provides for two measuring range options. The first probe version is equipped with a flexible cable and can be used when measuring in environments up to 80 °C. The second version is suitable for measuring in environments up to 120 °C.


See Appendix A on page 147 for the following probe installation kits for HMT333 and installation examples.

- Duct mounting kit
- Cable gland.

## HMT334 for High Pressure and Vacuum Applications

The HMT334 probe is for the dewpoint measurements in pressurized rooms and industrial processes. The probe is provided with a nut, a fitting screw and a sealing washer. Keep the fitting screw and the nut in place on the body of the probe during handling to prevent damage to the highly polished surface of the probe. Follow the instructions below to achieve a leak-tight assembly:

1. Remove the fitting screw from the nut and the probe.
2. Attach the fitting screw to the chamber wall with a sealing washer. Tighten the fitting screw into the threaded sleeve with a torque spanner. The tightening torque is  $150 \pm 10 \text{ Nm}$  ( $110 \pm 7 \text{ ft-lbs}$ ).
3. Insert the body of the probe into the fitting screw and attach the nut manually to the fitting screw so that the connection feels tight.
4. Mark both the fitting screw and the nut hex.




0506-029

**Figure 22 HMT344 Probe**

The following numbers refer to Figure 22 above:

- 1 = Tightening cone
- 2 = Nut
- 3 = Fitting screw, M22x1.5 or NPT 1/2"
- 4 = Sealing washer
- 5 = Probe; Ø12 mm.

5. Tighten the nut a further 30° (1/12) turn or if you have a torque spanner tighten it with a torque of 80 ± 10 Nm (60 ± 7 ft-lbs).




0503-034

**Figure 23 Tightening the Nut**

**NOTE**

When re-tightening the nut after detachment the nut must be tightened without increased effort.

6. Clean and grease the tightening cone of the fitting screw after every tenth detachment. Change the sealing washer every time the fitting screw is detached. Use high-vacuum grease (for example Dow Corning) or similar grease.



0503-033

**Figure 24** Cleaning of Tightening Cone

The following numbers refer to Figure 24 above:

- 1 = Fitting screw
- 2 = Sealing washer
- 3 = Tightening cone
- 4 = Clean cotton stick

**CAUTION**

In pressurized processes it is essential to tighten the supporting nuts and screws very carefully to prevent loosening of the probe by the action of pressure.

**NOTE**

When installed in a process with a pressure differing from normal atmospheric pressure, please enter the pressure value of the process (in hPa or mbar) into the transmitter memory via the serial line (see command PRES and XPRES on page 81) or by using display/keypad.

## HMT335 for High Temperatures

HMT335 is installed similarly than the HMT333 probe but without the supporting bar. Refer to Appendix A on page 147 for more information on the duct installation kit for HMT335.

To avoid incorrect humidity readings, the temperature differences between inside and outside of the duct must not be remarkable.

## HMT337 for High Humidity Applications

The HMT337 is for environment where relative humidity is very high, near saturation. The warmed probe prevents the saturation of the sensor. An additional temperature probe is also available.

See Appendix A on page 147 for a presentation of the following probe installation kits for HMT337 with installation examples:

- Duct mounting kit
- Cable gland
- Pressure tight Swagelok connector
- Vaisala's Meteorological Installation kit

The installation kits are available for both humidity and temperature probe.


## Temperature Probe (Optional)

An external temperature probe for HMT337 is needed for the measurement of the ambient temperature in case you have a transmitter with a warmed probe. This allows you to measure other humidity quantities apart from dewpoint and mixing ratio.

The temperature probe is connected always in factory.

## HMT338 for Pressurized Pipelines

Due to the sliding fit the HMT338 is easy to install into and remove from the pressurized process. The probe is especially suitable for the measurements in pipelines. See section Ball Valve Installation Kit for HMT338 on page 154.



**Figure 25 HMT338 Probe**

The following numbers refer to Figure 25 above:


- 1 = Clasp nut, 24 mm hex nut
- 2 = Fitting body, 27 mm hex head

The following two fitting body options are available:

- Fitting Body ISO1/2 solid structure
- Fitting Body NPT1/2 solid structure

**Table 4 HMT338 Probe Dimensions**


Probe type	Probe Dimension	Adjustment Range
Standard	178 mm	120 mm
Optional	400 mm	340 mm



**Figure 26 Sealing of Fitting Body into Process**

## Tightening the Clasp Nut

1. Adjust the probe to a suitable depth according to the type of installation.
2. Tighten the clasp nut first manually.
3. Mark the fitting screw and the clasp nut.
4. Tighten the nut a further 50 -60° (ca. 1/6 turn) with a wrench. If you have suitable torque spanner, tighten the nut to max 45 ± 5 Nm (33 ± 4 ft-lbs).



**Figure 27 Tightening the Clasp Nut**

The following numbers refer to Figure 27 on page 42:

- 1 = Probe
- 2 = Clasp nut
- 3 = Fitting screw
- 4 = Pen

**NOTE**

Take care not to over tighten the clasp nut to avoid difficulties when opening it.

**CAUTION**

Take care not to damage the probe body. A damaged body makes the probe less tight and may prevent it from going through the clasp nut.

**CAUTION**

In pressurized processes it is essential to tighten the supporting nuts and screws very carefully to prevent loosening of the probe by the action of pressure.


**NOTE**

When installed in a process with a pressure differing from normal atmospheric pressure, please enter the pressure value of the process (in hPa or mbar) into the transmitter memory via the serial line (see command PRES and XPRES on page 81) or by using display/keypad.

## Optional Modules

### Power Supply Module

The AC (mains) power connection may be connected to the power supply module only by an authorized electrician. A readily accessible disconnect device shall be incorporated in the fixed wiring.



**Figure 28 Power Supply Module**

The following numbers refer to Figure 28 above:

- 1 = Connect AC (mains) voltage wires to these terminals
- 2 = Grounding terminal
- 3 = In case the module is not installed in the factory: Connect wires from these terminals to the POWER 10 ... 36V 24V terminals of the mother board.
- 4 = +
- 5 = -

## Installation

1. Disconnect the power and open the transmitter cover.
2. Remove the protective plug from the cable gland and thread the wires. In case the power supply module is installed in the factory, continue with the step 5.
3. Attach the power module to the bottom of the housing with four screws. See the position Figure 2 on page 18.
4. Connect the wires from the terminals of the power supply module marked with + and - to the terminals **POWER 10 ... 35 V 24V** on the motherboard of the transmitter.
5. Connect the AC mains voltage wires to the power supply module terminals marked with **N** and **L**.
6. Attach the grounding wire to the grounding terminal on the right-hand side of the transmitter.
7. Connect the power. The LED on the cover of the transmitter is lit continuously during normal operation.

**WARNING**

Do not detach the power supply module from the transmitter when the power is on.

**WARNING**

Do not connect the mains power to power supply module when it is not installed in the transmitter.

**WARNING**

Always connect the protective ground terminal.

## Warnings

### **Dieses Produkt entspricht der Niederspannungsrichtlinie (73/23 EWG).**

- Das Netzmodul darf nur von einem dazu befugten Elektriker angeschlossen werden.
- Trennen Sie das Netzmodul nicht vom Messwertgeber, wenn der Strom eingeschaltet ist.
- Verbinden Sie das Netzmodul nur mit der Spannungsquelle, wenn es im Messwertgeber HMT330 montiert ist.
- Das Erdungskabel muss zum Schutz immer angeschlossen sein.

### **Ce produit est conforme à la Directive relative à la Basse Tension (73/23 EEC).**

- Seul un électricien compétent est habilité à raccorder le module d'alimentation au secteur.
- Ne pas détacher le module d'alimentation du transmetteur lorsqu'il est en service.
- Ne pas raccorder le secteur au module d'alimentation lorsque celui-ci n'est pas installé dans le transmetteur HMT330.
- Toujours raccorder un bornier de protection à la terre.

### **Tämä tuote on pienjännitedirektiivin (73/23 EEC) mukainen.**

- Vaihtovirtaliitännän saa kytkeä tehonsyöttömoduuliin ainoastaan valtuutettu sähköasentaja
- Älä irrota tehonsyöttömoduulia lähettimestä, kun virta on kytkettynä.
- Älä kytke verkkovirtaa tehonsyöttömoduuliin, jos kyseistä moduulia ei ole asennettu HMT330 lähettimeen.
- Kytke aina maadoitusliittimet.

### **Denna produkt uppfyller kraven i direktivet om lågspänning (73/23 EEC).**

- Nätanslutningen (växelströmsanslutningen) får bara anslutas till strömförsörjningsmodulen av en behörig elektriker.
- Ta inte loss strömförsörjningsmodulen från mätaren när strömmen är på.
- Anslut inte strömförsörjningsmodulen till nätet när den inte är installerad i HMT330-mätaren
- Anslut alltid en skyddande jordningsplint.

**Questo prodotto é conforme alla Direttiva sul basso voltaggio (73/23 CEE).**

- La conduttura elettrica può essere collegata al modulo di alimentazione elettrica soltanto da un elettricista autorizzato.
- Non staccare l'alimentazione elettrica dal trasmettitore quando é acceso.
- Non collegare la corrente elettrica al modulo di alimentazione elettrica se non é installato nel trasmettitore HMT330.
- Collegare sempre il morsetto protettivo a terra!

**Dette produkt er i overensstemmelse med direktivet om lavspænding (73/23 EØS).**

- Netstrømskoblingen til må kun tilsluttes strømforsyningsmodulet af en autoriseret elinstallatør
- Strømforsyningsmodulet må ikke løsghøres fra senderen, mens spændingen er sluttet til.
- Slut ikke netspændingen til strømforsyningsmodulet, når det ikke er installeret i HMT330-senderen
- Forbind altid den beskyttende jordklemme!

**Dit product voldoet aan de eisen van de richtlijn 73/23 EEG (Laagspanningsrichtlijn).**

- De stroom kan aan de stroomtoevoer module aangesloten worden alleen door een bevoegde monteur.
- Het is niet toegestaan de stroomtoevoer module van de transmitter los te koppelen wanneer de stroom aan is.
- Het is niet toegestaan de stroom aan de stroomtoevoer module aan te sluiten als deze niet in een HMT330-transmitter is gemonteerd.
- Altijd beschermend aardcontact aansluiten!

**Este producto cumple con la directiva de bajo voltaje (73/23 EEC).**

- La conexión de la alimentación principal al módulo de alimentación sólo puede realizarla un electricista autorizado.
- No desenchufe el módulo de alimentación del transmisor cuando esté encendido.
- No conecte la alimentación principal al módulo de alimentación cuando no esté instalado en el transmisor HMT330.
- Conecte siempre el terminal de protección de conexión a tierra.

**See toode vastab madalpinge direktiivile (73/23 EEC).**

- Voolukaabli võib vooluallika mooduli külge ühendada ainult volitatud elektrik.
- Äрге ühendage vooluallika moodulit saatja küljest lahti, kui vool on sisse lülitatud.
- Äрге ühendage voolukaablit vooluallika mooduli külge, kui seda pole HMT330-tüüpi saatjasse paigaldatud.
- Ühendage alati kaitsev maandusklemm!

**Ez a termék megfelel a Kisfeszültségű villamos termékek irányelvnek (73/23/EGK).**

- A hálózati feszültséget csak feljogosított elektrotechnikus csatlakoztathatja a tápegységmodulra.
- A bekapcsolt távadóról ne csatolja le a tápegységmodult.
- Ne csatlakoztassa a hálózati feszültséget a tápegységmodulhoz, ha az nincs beépítve a HMT330 távadóba.
- Feltétlenül csatlakoztasson földelő védőkapcsot!

**Šis produktas atitinka direktyvą dėl žemos įtampos prietaisų (73/23/EB).**

- Elektros tinklą su energijos tiekimo modulių sujungti gali tik įgaliotas elektrikas.
- Niekada neišimkite energijos tiekimo modulio iš siūstuvo, kai maitinimas yra įjungtas.
- Jei energijos tiekimo modulis nėra įmontuotas HMT330 siūstuve, nejunkite jo į elektros tinklą.
- Visada prijunkite prie apsauginės žeminimo jungties!

**Šis produktas atbilst Zemsprieguma direktivai (73/23 EEC).**

- Strāvas pieslēgumu var pieslēgt pie barošanas avota moduļa tikai autorizēts elektriks.
- Neatvienot barošanas avota moduli no raidītāja, kad pieslēgta strāva.
- Nepievienot strāvu barošanas avota moduļim, ja tas nav uzstādēts HMT330 raidītājā
- Vienmēr pievienot aizsargājošu iezemētu terminālu !

**Ten produkt spełnia wymogi Dyrektywy niskonapięciowej (73/23 EEC).**

- Napięcie zasilające powinno zostać podłączone do modułu zasilacza tylko przez wykwalifikowanego elektryka.
- Nie wolno odłączać modułu zasilacza od nadajnika, kiedy zasilanie jest włączone.
- Nie wolno podłączać napięcia zasilającego do modułu zasilacza, kiedy nie jest on zamontowany w nadajniku HMT330.
- Zawsze należy podłączać zabezpieczający zacisk uziemiający!

**Tento výrobek vyhovuje Směrnici pro nízké napětí (73/23 EEC).**


- Připojení síťového napájení k napájecímu modulu smí provádět pouze oprávněný elektrikář.
- Neodpojujte napájecí modul od snímače při zapnutém napájení.
- Nepřipojujte síťové napájení k napájecímu modulu, pokud není instalován ve snímači HMT330.
- Vždy zapojte ochrannou zemnicí svorku!

## Galvanic Isolation for Output

If galvanic isolation of the power supply line from the output signals is needed, HMT330 can be ordered with optional output isolation module. This module prevents harmful grounding loops.

### NOTE

Output isolation module is not needed when using the power supply module.




**Figure 29 Galvanic Output Isolation Module**

The following number refers to Figure 29 above:

1 = Output isolation module

## Third Analog Output



**Figure 30 Third Analog Output**

The following numbers refer to Figure 30 above:

- 1 = Flat cable pins
- 2 = Screw terminals for signal line
- 3 = DIP switches to select the output mode and range

## Installation and Wiring

1. Disconnect the power. In case the analog output module is installed in the factory, continue with the step 4.
2. Open the transmitter cover and fasten the analog output module to the position for MODULE 2 with four screws. Refer to Figure 2 on page 18.
3. Connect the flat cable between the analog output module and the motherboard's connector for MODULE 2.
4. Take out the protective plug from the cable gland and thread the wires.
5. Connect the wires to the screw terminals marked with **Ch+** and **Ch-**.
6. Select the current/voltage output by setting ON either of the switches 1 or 2.
7. Select the range by setting ON one of the switches 3 ... 7.

**NOTE**

Only one of the switches 1 and 2 can be ON at a time.

Only one of the switches 3 ... 7 can be ON at a time.

	OFF	ON	Selection
Channel 3	1		Current output selection, ON=Current output selected
	2		Voltage output selection, ON=Voltage output selected
	3		0...20 mA selection, ON= 0...20 mA selected
	4		4... 20 mA selection, ON= 4... 20 mA selected
	5		0...1 V selection, ON=0...1 V selected
	6		0...5 V selection, ON=0...5 V selected
	7		0...10 V selection, ON= 0...10 V selected.
	8		For service use only, keep always in OFF position.

0508-029

**Figure 31 Third analog output selection**

8. Connect the power.
9. Select the quantity and scale the channel via the serial line or display/keypad, see section Analog Output Quantities on page 95. For testing the analog output, see section Analog Output Tests on page 97. For fault indication setting, see section Analog Output Fault Indication Setting on page 98.

## Relays

HMT330 can be equipped with one or two configurable relay modules. Each module contains two configurable relays. See the contact ratings in section Technical Specifications of Optional Modules on page 139.

### Installation and Wiring

1. Disconnect the power and open the transmitter cover. In case the relay-module is installed in the factory, continue with step 5.
2. Attach the relay module to the bottom of the housing with four screws. See the position in Figure 2 on page 18.
3. When the mains power is in use attach the grounding wire to the grounding terminal.
4. Connect the flat cable between the relay module and the **MODULE 1** or **MODULE 2** pins of the motherboard.
5. Take out the protective plug from the cable gland and thread the relay wires.
6. Connect the wires to the screw terminals: NO, C, NC.

### Selecting the Activation State of the Relay


The middlemost C terminal and either one of the terminals NO/NC must be connected. The polarity can be freely selected.

NO Normally open  
C Common relay  
NC Normally closed

Relay NOT activated: C and NC outputs are closed, NO is open  
Relay IS activated: C and NO outputs are closed, NC is open.  
Connect the power and close the cover.

**NOTE**

For instructions on how to operate the relay (for example, select quantity for the relay output and set the relay setpoints) see section Operation of Relays on page 99.



0503-037

**Figure 32 Relay Module**

The following numbers refer to Figure 32 above:

- 1 = Indication led for the relay 1 or 3
- 2 = Relay test buttons
- 3 = Flat cable pins
- 4 = Indication led for relay 2 or 4


**WARNING**

The relay module may contain dangerous voltages even if the transmitter power has been disconnected. Before opening the transmitter you must switch off **both** the transmitter **and** the voltage connected to the relay terminals.

**WARNING**

Do not connect the mains power to relay unit without grounding the transmitter.

## RS-422/485 Interface



0503-029

**Figure 33 RS-485 Module**

The following numbers refer to Figure 33 above:

- 1 = Flat cable pins
- 2 = Selection switches
- 3 = Screw terminals for wiring

### Installation and Wiring

1. Disconnect the power. In case the RS-485-module is installed in the factory, continue with the item 4.
2. Open the transmitter cover and attach the RS-485 module to the bottom of the housing with four screws.
3. Connect the flat cable between the RS-485 module and the motherboard's pins **MODULE1 (Communications)**.
4. Pull the network wirings through the cable gland.
5. Connect the twisted pair wires (1 or 2 pairs) to the screw terminals as presented in Table 5 below:

**Table 5 Connecting the Twisted Pair Wires to the Screw Terminals**

Screw terminal	Data line (2-wire RS-485)	Data line (4-wire RS-485/422)
1	(not connected)	RxB
2	(not connected)	RxA
3	Data pair shield	Data pair shield
4	B	TxB
5	A	TxA

6. If you use RS-485 (or RS-422) to connect just one HMT330 to a master computer, enable the internal termination of HMT330 by switching switches 1 and 2 ON. Make sure that the master's end of the line is also terminated (by using master's internal termination or with a separate terminator).

If you are connecting many transmitters to the same RS-485 bus, make sure that switches 1 and 2 are OFF and terminate the bus with separate terminators at both ends. This allows removing any transmitter without blocking the bus operation.

**NOTE** If you use the internal termination of the transmitter at the end of the RS-485 bus (instead of using separate terminators) removing that transmitter will block the bus operation.

7. Use the bus type (4-wire/2-wire) to select the selection switch 3. In 4-wire mode RS-485 master sends data to the HMT330 through terminals RxA and RxB and receives data from HMT330 through terminals TxA and TxB.





Figure 34 4-Wire RS-485 Bus

Table 6 4-Wire (Switch 3: On)

RS-485 master	Data	HMT330
TxA	→	RxA
TxB	→	RxB
RxA	←	TxA
RxB	←	TxB



**Table 7 2-Wire (Switch 3: Off)**

RS-485 master	Data	HMT330
A	↔	A
B	↔	B

8. When operating in communication mode RS-422, set both switches 3 and 4 to ON position (4-wire wiring is required for RS-422 mode).
9. Connect the power and close the cover.

## Data Logger Module

The optional data logger module extends the data storage for the measurement data. When the data logger is present, this storage is automatically used by the transmitter. The stored data can be browsed using the optional display module, and accessed through the serial connections. See sections Graphic History on page 60 and Data Recording on page 90.


The data logger module contains non-volatile flash memory providing 4 years 5 months of storage for 3 parameters at a 10 second sampling interval. For each parameter, the module stores the minimum and maximum values during the interval, as well a data trend value that is averaged from samples taken during the interval.

The data logger module has a real time clock with a battery back-up. The clock has been set to the Coordinated Universal Time (UTC) at

the factory, and its time cannot be set by the user. The data that is stored in the logger's memory is timestamped using the logger's clock.

When date and time are set on the transmitter, they are stored to the transmitter's memory as an offset from the time on the logger's clock. When browsing the stored data, the time offset is applied to the timestamps shown in the graphical history, and data outputted from the serial port. The timestamps in the data logger's memory remain as they were originally stored.

You can compensate for the clock drift (less than  $\pm 2$  min/year) by setting the time on the transmitter. This updates the time offset used on the display and the serial port. You can set the time by using the keypad/display or the serial commands.



0706-068

**Figure 35 Data Logger Module**

The following numbers refer to Figure 35 above:

- 1 = Flat cable pins
- 2 = Battery


After a reset or a power up, it will usually take at least 10 seconds before the data logger module is initialized. The real time clock and the data logging and reading functions are not available before the initialization is complete.

The indicator LED on the module will blink green during normal operation. If the LED is lit in red color, there is a problem with the module. The transmitter will also indicate the problem by activating the "Add-on module connection failure" error. If the module is not operating correctly, the transmitter must be sent to Vaisala for maintenance.

The data logger module must be installed at the factory. Once installed, the module is automatically used by the transmitter. When

the module requires a new battery, the transmitter must be sent to Vaisala for maintenance.

## 8-Pin Connector



0503-026

**Figure 36** Wiring of Optional 8-Pin Connector

**Table 8** Wiring of 8-Pin Connector

PIN/Terminal	Wire	Serial Signal		Analog Signal
		RS-232 (EIA-232)	RS-485 (EIA-485)	
1	White	Data out TX	A	-
2	Brown	(serial GND)	(serial GND)	Signal GND (for both channels)
3	Green	-	-	Ch 2+
4	Yellow	-	-	Ch 1 +
5	Grey	Supply -	Supply -	Supply -
6	Pink	Supply +	Supply +	Supply +
7	Blue	Data in RX	B	-
8	Shield/Red	Cable shield	Cable shield	Cable shield

This page intentionally left blank.

## CHAPTER 4

# OPERATION

This chapter contains information that is needed to operate this product.

## Getting Started


Within a few seconds after power-up the LED on the cover of the transmitter is lit continuously indicating normal operation. When using the optional display and turning the transmitter on the first time, the language selection menu window opens. Select the language with ▼ ▲ arrow buttons and press the **SELECT** button (the left-hand  button).

The pressure has an effect on humidity calculations and accuracy. Therefore, accurate calculations can be achieved only when the ambient pressure is taken into consideration. For instructions on how to set the pressure, see section Pressure Compensation Setting on page 80.

## Display/Keypad (Optional)

### Basic Display

Display shows you the measurement values of the selected quantities in the selected units. You can select 1 ... 3 quantities for the numerical basic display (see section Changing Quantities and Units on page 77.)



0705-209

**Figure 37 Basic Display**

The following numbers refer to Figure 37 above:


- 1 = The Info shortcut button, see section Device Information on page 86
- 2 = The Graph shortcut button, see section Graphic History on page 60
- 3 = Quantities selected for display

**NOTE**

From any view, a four-second press on the right-hand function button takes you directly to the basic display.

## Graphic History

The graphical display shows the data trend or min/max graph of the selected quantities, one at a time. The graph is updated automatically while measuring.



0705-210

**Figure 38 Graphical Display**

**Trend graph:** Shows you a curve of average values. Each value is a calculated average over a period. See Table 9 on page 61 below.

**Max/min graph:** Shows you the minimum and maximum values in a form of curve. Each value is max/min over a time period. See Table 9 below.


**Table 9 Periods for Trend and Max/Min Calculations**

Observation Period	Period for Trend/Max/Min Calculations (Resolution)
20 minutes	10 seconds
3 hours	90 seconds
1 day	12 minutes
10 days	2 hours
2 months	12 hours
1 year	3 days
4 year*	12 days

\* Shows the maximum logging period of the data logger module (available when data logger module is installed)

Use the following functions in the graphical display:

- Press the **NEXT** button to change between the trend graph and max/min graph for the quantities selected for display.
- Press the **EXIT** button to return to the basic display.
- Press the **▼ ▲** arrow buttons to zoom in and out in the graph window.
- Press the **◀ ▶** arrow buttons move the cursor (vertical bar) along the time axis. The cursor mode allows you to observe individual measuring points. The numerical value at the cursor position is shown at the left upper corner. The right upper corner shows the time from the present to the chosen moment (without the logger module), or the date and time at the cursor position (when the logger module is installed).
- If the optional data logger module is installed, you can scroll the cursor off the screen to move to a new point on the time axis. The new date will be displayed, and the cursor will be centered at the date where the cursor scrolled off the screen.



**Figure 39 Graphical Display with Data Logger**

The time that is shown below the graph is adjusted with the current time offset of the transmitter. If you change the transmitter's date and time setting, the displayed timestamps in the history graph change accordingly. For an explanation of the effect of changing the date and time manually, see section Data Logger Module on page 55.

**Table 10 Graph Information Messages in Cursor Mode**


Message	Interpretation
Power outage	Power failure (marked also with dashed vertical line)
No data	Quantity has not been selected for the display
Device failure	General device failure
T meas. failure	Temperature measurement/sensor failure
RH meas. failure	Humidity measurement/sensor failure
Adj. mode active	Adjustment mode active (data recorded in the adjustment mode is not displayed)

A question mark after time tells you that at least one power failure (dashed vertical line) has occurred after the chosen moment. In this case, the exact time difference between the present and the cursor position is not exactly known.

## Menus and Navigation

You can change settings and select functions in the menus.

1. Open the **MAIN MENU** by pressing any of the ▼ ▲ ◀ ▶ arrow buttons in the basic (numeric) display mode.
2. Move in the menus by using the ▲ ▼ arrow buttons.
3. Open a submenu with ▶ button.
4. Press ◀ to return to the previous level.
5. Function button **EXIT** returns you back to the basic display.



0705-208

**Figure 40** Main Menus

Some menu items, such as **Purge** in the **Measuring** menu, are only shown if supported by the transmitter and the installed options.

## Changing the Language

1. Go back to the basic display by keeping the right-hand  button pressed for four seconds.
2. Open the **Main menu** by pressing any of the     buttons.
3. Scroll to the **System** menu option, and press the  button. The menu option is indicated with the wrench  symbol.
4. Scroll to the **Language** menu option, and the left-hand  button. The menu option is indicated with the flag  symbol.
5. Select the language with the   buttons, and confirm the selection by pressing the left-hand  button.
6. Press the right-hand  button to exit to the basic display.

## Rounding Setting

Round off one decimal by using the Rounding function. The default setting is rounding on. Rounding has no effect on quantities without decimals.

1. Open the **MAIN MENU** by pressing any of the **▼▲◀▶** arrow buttons.
2. Select **Display** and confirm by pressing the **▶** arrow button.
3. Select **Rounding** and press **ON/OFF** button.
4. Press **EXIT** to return to the basic display.

## Display Backlight Setting

As a default the display backlight is always on. In the automatic mode the backlight stays on for 30 seconds from the last press of any button. When pressing any button, the light turns on again.

1. Open the **MAIN MENU** by pressing any of the **▼▲◀▶** arrow buttons.
2. Select **Display**, press the **▶** arrow button.
3. Select **Backlight**, press the **CHANGE** button.
4. Select **On/Off/Automatic**, press the **SELECT** button.
5. Press **EXIT** to return to the basic display.

## Display Contrast Setting

1. Open the **MAIN MENU** by pressing any of the **▼▲◀▶** arrow buttons.
2. Select **Display**, press the **▶** arrow button.
3. Select **Contrast**, press the **ADJUST** button.
4. Adjust the contrast by pressing the **◀▶** arrow buttons.
5. Press **OK** and **EXIT** to return to the basic display.

## Keypad Lock (Key guard)

This function locks the keypad and prevents unintentional key presses.

1. Keep pressing the left-hand function button for 4 seconds to lock the keypad (at any display).
2. To unlock the keypad, press the **OPEN** button for 4 seconds.

## Menu PIN Lock

You can prevent unauthorized changes of the device settings by activating the menu PIN lock. When this function is activated, the basic display and graphical view are available but access to the menus is locked. The key symbol indicates the activation of this feature.

1. Open the **MAIN MENU** by pressing any of the ▼▲◀▶ arrow buttons.
2. Select **System**, press the ► arrow button.
3. Select **Menu PIN**, press the **ON** button.
4. Enter a PIN code by using the ▼▲ arrow buttons. Press **OK** to confirm the setting. Now the PIN lock is on and a key symbol is shown in a display.
5. Press **EXIT** to return to the basic display. Returning to the menu is possible only by entering the correct PIN code.

When you want to turn off the PIN lock, go to the menu by giving the PIN code and select **System, Menu PIN**, press **OFF** button.

In case you have forgotten the PIN code, open the transmitter cover and press the **ADJ** button once. Wait for a few seconds and the adjustment menu opens. Select **Clear menu PIN**, press  **CLEAR**.

### NOTE

You can also disable the keypad completely with serial command **LOCK**.

## Factory Settings

Use the display/keypad to restore the factory settings. This operation does not affect the adjustments. Only settings available in the menus are restored.

1. Press any of the arrow buttons to open the **MAIN MENU**.
2. Select **System** by pressing the ► arrow button.
3. Select **Factory settings** and press the **REVERT** button to confirm your selection. Press the **YES** button to reset all settings to the factory defaults.

See section General Settings on page 77 for a description of the other menu options.

## MI70 Link Program for Data Handling

The recorded data can be transferred to a PC by using MI70 Link program. You can examine the recorded data easily in Windows environment and transfer it further to a spreadsheet program (such as Microsoft Excel) or virtually to any Windows program in numeric or graphical format. MI70 Link program allows you also to monitor transmitter readings directly with a PC (real-time window function).

Use a MI70 Link version 1.07, or a newer one, to be able to utilize all the functions of HMT330.

1. Connect your PC to the Service Port of the HMT330 using a suitable connection cable. Refer to section Service Port Connection on page 68.
2. Check that the HMT330 is powered.
3. Start using the MI70 Link program. The program detects the connection type automatically; there is usually no need to select a COM port manually.


The MI70 Link program, and the optional connection cables, are available from Vaisala. See list of accessories in section Options and Accessories on page 141.

## Serial Line Communication

Connect the serial interface by using either the user port or the service port.

For permanent interfacing to host system, use the user port. You can change the serial settings and operate in RUN, STOP and POLL modes.

For temporary connections, use the service port. The service port is always available with fixed serial settings.



0605-039

**Figure 41 Service Port Connector and User Port Terminal on Mother Board**

The following numbers refer to Figure 41 above:


- 1 = Service port connector
- 2 = User port terminals

## User Port Connection

Use a suitable serial cable between the user port RxD, GND and TxD screw terminals and the PC serial port, see Figure 42 on page 68.

**Table 11 Default Serial Communication Settings for the User Port**

Parameter	Value
Bauds	4800
Parity	Even
Data bits	7
Stop bits	1
Flow control	None



**Figure 42 Connection Example Between PC Serial Port and User Port**

Connections to pins 4, 6, 7 and 8 on PC serial port are required only if you are using software requiring hardware handshaking.

After power-up the transmitter (in STOP-mode) outputs the software version and the command prompt.

```
HMT330/4.03
>
```

In RUN mode a measurement output starts immediately after power-up.

In POLL mode, the transmitter does not output anything after power-up (see section SMODE on page 107).

**NOTE** User port cannot be used when the RS-485 module is connected.

## Service Port Connection

### Connection Cables

To connect to the service port, you need a suitable cable with an RJ45 connector. Depending on the connections of your PC, you can either use the Serial Connection Cable (optional accessory 19446ZZ) or the USB-RJ45 Serial Connection Cable (optional accessory 219685). The USB cable enables you to connect the transmitter to a PC via a standard type A USB port. Note that the USB cable does not enable high speed data transfer, since the bit rate is limited by the serial interface of the service port.

## Installing the Driver for the USB Cable

Before taking the USB cable into use, you must install the provided USB driver on your PC. When installing the driver, you must acknowledge any security prompts that may appear. The driver is compatible with Windows® 2000, Windows® XP, Windows Server® 2003, and Windows® Vista.

1. Check that the USB cable is not connected. Disconnect the cable if you have already connected it.
2. Insert the media that came with the cable, or download the driver from [www.vaisala.com](http://www.vaisala.com).
3. Execute the USB driver installation program (setup.exe), and accept the installation defaults. The installation of the driver may take several minutes.
4. After the driver has been installed, connect the USB cable to a USB port on your PC. Windows will detect the new device, and use the driver automatically.
5. The installation has reserved a COM port for the cable. Verify the port number, and the status of the cable, using the **Vaisala USB Instrument Finder** program that has been installed in the Windows Start menu.

Windows will recognize each individual cable as a different device, and reserve a new COM port. Remember to use the correct port in the settings of your terminal program. If you are using the Vaisala MI70 Link application, you do not need to check the COM port, as the MI70 Link detects the USB connection automatically.

There is no reason to uninstall the driver for normal use. However, if you wish to remove the driver files and all Vaisala USB cable devices, you can do so by uninstalling the entry for **Vaisala USB Instrument Driver** from the **Add or Remove Programs (Programs and Features** in Windows Vista) in the Windows Control Panel.

## Using the Service Port

1. Unfasten the screws on the transmitter cover, and open the transmitter.
2. Connect the desired cable (serial interface cable or USB cable) to your PC and the service port connector on the transmitter. For the location of the service port, refer to Figure 41 on page 67.
3. Open a terminal program and set the communication settings as follows:

**Table 12** Communication Settings for the Service Port

Parameter	Value
Bauds	19200
Parity	None
Data bits	8
Stop bits	1
Flow control	None

For a detailed explanation of using a terminal program, see section Terminal Program Settings on page 70.

4. Power-up the HMT330.

## Terminal Program Settings

The following instructions show a connection example with HyperTerminal program (included in the Microsoft Windows®).

Follow the instructions below to open a HyperTerminal program:

1. Start HyperTerminal. To get help for starting HyperTerminal, click "Start", select "Help" to open Windows help, and search for "HyperTerminal".



**Figure 43** Starting Hyper Terminal Connection


2. In the "New Connection" window of the HyperTerminal, define a name for HMT330 serial connection, for example "HMT330". Click OK.
3. In the "Connect using" pull down menu, select the PC communications port where the serial cable is connected. (If

your computer has only one COM port, it is called "COM1"). Click OK.



**Figure 44** Connecting to Hyper Terminal

4. Set the port settings in the "Properties" window to match the settings of your HMT330 *user port/service port*. For HMT330, "Flow control" must always be set to "None". Finally click OK to start using the serial connection.



**Figure 45** Hyper Terminal Serial Port Settings

5. Select "File" → "Save" in the HyperTerminal main window to save the serial port settings. To use the saved settings later, start HyperTerminal, click cancel in the "New Connection" window, and select "File" → "Open".

## List of Serial Commands

The **bold** text in the brackets is the default setting. To issue a command, type it on your computer and press the Enter key.

**Table 13 Measurement Commands**

Command	Description
R	Start the continuous outputting
S	Stop the continuous outputting
INTV [ <b>0</b> ... 255 <b>S</b> /MIN/H]	Set the continuous output interval (for RUN mode)
SEND [ <b>0</b> ... 99]	Output the reading once
SEND D	Outputting the reading with the raw data
SMODE [ <b>STOP</b> /RUN/POLL]	Set the serial interface mode
SDELAY	View or set user port (RS232 or RS485) answer minimum delay
SERI [baud p d s]	User Port settings (Default: 4800 E 7 1) baud: 300 ... 115200
ADDR [ <b>0</b> ... 99]	Set the transmitter address (for POLL mode)
OPEN [ <b>0</b> ... 99]	Open a temporary connection to a POLL mode device
CLOSE	Close the temporary connection (Back to POLL mode)

**Table 14 Formatting Commands**

Command	Description
FORM	Set the output format of SEND and R commands
TIME	Set the time
DATE	Set the date
FTIME [ <b>ON</b> / <b>OFF</b> ]	Add time to SEND and R outputs
FDATE [ <b>ON</b> / <b>OFF</b> ]	Add date to SEND and R outputs
FST [ <b>ON</b> / <b>OFF</b> ]	Add the state of probe heating and chemical purge in connection with SEND and R commands
UNIT	Select the metric or non-metric output units

**Table 15 Data Recording Commands**

Command	Description
DIR	Display recorded files
PLAY [0 ... 21] [START END]	Output recorded data file. Start and end times can only be specified if the data logger module is installed. The times must be given in the following format: yyyy-mm-dd hh:mm:ss
DSEL	Select data recording and display quantities.
DELETE	Delete all data files, including the memory of the optional data logger module

Command	Description
UNDELETE	Recover the deleted files that have not been overwritten

**Table 16 Chemical Purge Commands**

Command	Description
PUR	Set the automatic chemical purge
PURGE	Start the manual chemical purge

**Table 17 Calibration and Adjustment Commands**

Command	Description
CRH	Relative humidity calibration
CT	Temperature calibration
CTA	Additional temperature probe calibration
FCRH	Relative humidity calibration after sensor change
CTEXT	Give the text to calibration information field
CDATE	Set the calibration date
ACAL	Analog output calibration

**Table 18 Setting and Testing the Analog Outputs**

Command	Description
AMODE	View the analog output modes
ASEL	Select the parameters for the analog outputs
ITEST	Test the analog outputs
AERR	Change the analog error output values

**Table 19 Setting and Testing the Relays**

Command	Description
RSEL	Set and view the relays
RTEST	Test the relays

**Table 20 Other Commands**

Command	Description
?	Output information about the device
??	Output information about the device in POLL mode
ECHO [ON/OFF]	Turn the serial interface echo ON/OFF
ERRS	List present transmitter errors
FILT	Set the result filtering
FIND	All devices in POLL mode send their addresses
HELP	List the most common commands
LOCK	Lock the menu and disable the keypad
PRES [hPa]	Set the value for pressure compensations
VERS	Display the software version information
XHEAT	Sensor heating
XPRES [hPa]	Set the value for pressure compensations, temporarily

## Getting Measurement Message from Serial Line

### Starting Continuous Outputting

R

Enter the **R** command to start the continuous output of measurements.

#### Example:

```
>r
RH= 60.5 %RH T= 23.7 'C Tdf= 15.6 'C Td= 15.6 'C a= 13.0
g/m3 x= 11.1 g/kg Tw= 18.5 'C H2O= 17889 ppmV pw=
17.81 hPa pws= 29.43 hPa h= 52.3 kJ/kg dT= 8.1 'C
```

If a value is too long to fit to the allocated space in the output, or if there is an error in outputting the quantity, the value is displayed with stars '\*'.

#### Example:

```
RH=***.* %RH T= 31.0 'C
```

You can change the format of the output with the following commands:

- Outputting interval can be changed with the **INTV** command.
- Output message format can be changed with the **FORM** command.
- Status of chemical purge and probe heating can be added with the **FST** command.
- Date and time information can be added with commands **FDATE** and **FTIME**

## Stopping Continuous Outputting

### S

Use the **S** command to end the RUN mode. After this command all other commands can be used. You can also press the Esc button or reset the transmitter to stop the outputting.

See command **SMODE** to change the default (power-up) operation mode.

## Outputting Reading Once

### SEND

Use the **SEND** command to output the reading once in STOP mode. The output format depends on which parameters the transmitter can output.

#### Examples:

```
RH= 98.4 %RH T= 31.1 'C
```

```
RH= 98.4 %RH T= 31.1 'C Td= 36.0 'C Tdf= 36.0 'C a= 42.4  
g/m3 x= 38.8 g/kg Tw= 30.8 'C ppm= 62414 pw= 59.53  
hPa pws= 60.52 hPa h= 130.7 kJ/kg
```

## Outputting Reading with Raw Data

### SEND D

#### Example:

```
>send d  
24.1720 15.0399 -3.5743 189.2324 15.0709 15.0399  
23.9765
```

Where the readings (from the left) are:

24.1720 = Temperature of the humidity probe ( °C)  
15.0399 = RH (%RH)  
-3.5743 = Tdf (C)  
189.2324 = Capacitance (pF)  
15.0709 = RH raw: calculated from scaled capacitance (%RH)  
15.0399 = Enhancement factor corrected RH (%RH)  
23.9765 = Temperature of the additional temperature probe  
(optional) (°C)

## Formatting Serial Line Message

### FTIME and FDATE

**FTIME** and **FDATE** commands will enable/disable output of time and date to the serial line. To add time to **R** and **SEND** outputs enter:

**FTIME** [x]

To add date to **R** and **SEND** outputs enter:

**FDATE** [x]

where

x = ON or OFF

### Example:

```
>send
RH= 98.4 %RH T= 31.0 'C
>ftime on
Form. time      : ON
>send
03:47:59 RH= 98.4 %RH T= 31.0 'C
>fdate on
Form. date      : ON
>send
2004-07-05 03:48:03 RH= 98.4 %RH T= 31.0 'C
>
```

### FST

To output the state of optional probe heating and chemical purge in connection with **SEND** and **R** commands enter:

**FST** [x]

Where

x = ON or OFF (default)

### Example:

```
>fst on
Form. status   : ON
>send
N   0 RH= 40.1 %RH T= 24.0 'C Td=  9.7 'C Tdf=  9.7 'C
a=  8.7 g/m3   x=   7.5
g/kg Tw= 15.6 'C ppm= 11980 pw=  12.00 hPa pws=  29.91
hPa h=  43.2 kJ/kg
>purge
Purge started, press any key to abort.
>send
S 134 RH= 40.2 %RH T= 24.1 'C Td=  9.8 'C Tdf=  9.8 'C
a=  8.8 g/m3   x=   7.5
g/kg Tw= 15.7 'C ppm= 12084 pw=  12.10 hPa pws=  30.11
hPa h=  43.5 kJ/kg
>
```

For more information on chemical purge, see section Chemical Purge (Optional) on page 110.

Where the state of the probe is indicated by the following letters and values:

N ... xxx	=	Normal operation	where h xxx	=	Probe heat power
X ... xxx	=	Sensor heating	where xxx	=	Sensor temperature (°C)
H ... xxx	=	Chemical purge	where xxx	=	Sensor temperature (°C)
S ... xxx	=	Sensor cooling after purge	where xxx	=	Sensor temperature (°C)

## General Settings

### Changing Quantities and Units

To change quantities and units use serial commands or the optional display/keypad. See Table 2 on page 15 for available quantities and Table 3 on page 16 for optional quantities.

#### NOTE

Only the quantities selected when ordering the device can be selected as a display output quantity.

#### Using Display/Keypad

Use display/keypad to select the display output quantities.

1. Press any of the arrow buttons to open the **MAIN MENU**.

2. Press the ► arrow button to select **Display**.
3. Press ► arrow button to select **Quantities**.
4. Select the quantity by using the ▲▼ arrow buttons. Confirm the selection by pressing **SELECT**. You can select 1 ... 3 display quantities at a time.
5. Press **EXIT** to return to the basic display.

To select display units:

1. Press any of the arrow buttons to open the MAIN MENU.
2. Press the ► arrow button to select **Display**.
3. Use the ▲▼ arrow buttons to select **Units**. Confirm the selection by pressing the right-hand arrow button.
4. Use the ▲▼ arrow buttons to select display units. Confirm the selection by pressing **CHANGE**. The unit changes from metric to non-metric or the other way round.
5. Press **EXIT** to return to the basic display.

**NOTE**

Changing the display quantities/units (by using the display/keypad) has no effect on the serial output data.

## Using Serial Line

Use the serial line command **FORM** to change the format or select a certain quantities for the output commands **SEND** and **R**. Use the serial line command **UNIT** to select metric or non-metric output units.

### FORM

Use the serial line command **FORM** to change the format or select a certain quantities for the output commands **SEND** and **R**.

#### **FORM** [x]

where

x = Formatter string

Formatter string consists of quantities and modifiers.

When entering the command, use the abbreviations of the quantities. For more information on quantities, see Table 2 and Table 3 on page 15.

The modifiers are presented in Table 21 below.

**Table 21 FORM Command Modifiers**

Modifier	Description
x.y	Length modifier (number of digits and decimal places)
#t	Tabulator
#r	Carriage-return
#n	Line feed
""	String constant
#xxx	Special character, code "xxx" (decimal), for example #027 for ESC
U5	Unit field and length
ADDR	Transmitter address with two characters [00...99]
ERR	Error flags for P, T, Ta, RH [0000 ... 1111], 0 = no error
STAT	Transmitter status in 7 character field, for example: N 0 no heating h 115 probe heating active, power 115/255 H 159.0 purge heating active, temperature 159°C S 115.0 purge cooling active, temperature 115°C X 95.0 sensor heating active, temperature 95°C
SN	Transmitter serial number
TIME	Time [hh:mm:ss]
DATE	Date [yyyy-mm-dd]
OK	Pressure stability indicator, two characters [OK or " "]
CS2	Modulus-256 checksum of message sent so far, ascii encoded hexadecimal notation
CS4	Modulus-65536 checksum of message sent so far, ascii encoded hexadecimal notation
CSX	NMEA xor-checksum of message sent so far, ascii encoded hexadecimal notation
A3H	Pressure tendency [* or 0...8]

### Example:

```
>form "RH=" 4.2 rh U5 #t "T=" t U3 #r #n
RH= 14.98%RH T= 74.68'F
```

```
>send
RH= 16.03%RH T= 74.66'F
```

```
>form "Tfrost=" tdf U3 #t "Temp=" t U3 #r#n
Tfrost= 36.0'C Temp= 31.0'C
>
```

Command '**FORM /**' will return the default output format. The default output format depends on the device configuration.

```
>form /
>send
RH= 98.4 %RH T= 31.1 'C
>
```

## UNIT

Use the **UNIT** command to select metric or non-metric output units:

**UNIT** [x]

where

x = M or N

where

M = Metric units

N = Non-metric units

**NOTE**

This command changes both the serial output and display units to either metric or non-metric units. When you want to output both metric and non-metric units simultaneously on the display, select the display units later by using the display/keypad.

## Pressure Compensation Setting

The pressure has an effect on humidity calculations and accuracy. Therefore, accurate calculations can be achieved only when the process pressure is taken into consideration.

Note that conversions from mmHg and inHg are defined at 0°C and for mmH<sub>2</sub>O and inH<sub>2</sub>O at 4°C.

**NOTE**

Pressure compensation is intended to be used in normal air only. When measuring in other gases, please contact Vaisala for further information.

## Using Display/Keypad

Use display/keypad to set the pressure compensation. To select the pressure unit using display/keypad, see section Changing Quantities and Units on page 77.

1. Press any of the arrow buttons to open the MAIN MENU.
2. Select **Measuring** and press the ► arrow button to confirm your selection.
3. Select Pressure compensation and press the ► arrow button to confirm you selection.
4. Press **SET** and enter the pressure value in the chosen unit by using the arrow buttons.
5. Press **OK** and **EXIT** to return to the basic display.

## Using Serial Line

### PRES and XPRES

Command **XPRES** should be used if the value is changed frequently. Its value is not retained at reset, and when set to 0; last value set with **PRES** is used instead. Use the serial line and do the following:

**PRES** [aaaa.a]

**XPRES** [aaaa.a]

where

aaaa.a =Absolute process pressure (hPa)

### Example:

```
>pres
Pressure      : 1013.00 hPa ?
>pres 2000
Pressure      : 2000.00 hPa
>
```

**Table 22** Multiplication Factors

From	To: hPa
mbar	1
Pa N/m <sup>2</sup>	0.01
mmHg torr	1.333224
inHg	33.86388
mmH <sub>2</sub> O	0.09806650
inH <sub>2</sub> O	2.490889
atm	1013.25
at	980.665
bar	1000
psia <sup>1)</sup>	68.94757

1) psia = psi absolute.

### Example:

$29.9213 \text{ inHg} = 29.9213 \times 33.86388 = 1013.25 \text{ hPa}$

## Date and Time

### Using Display/Keypad

If the optional Data Logger Module is installed, you can change the time and date using the display/keypad.

1. Press any of the arrow buttons to open the MAIN MENU.
2. Select **System** and press the ► arrow button to confirm your selection.
3. Select **Date and time** and press the ► arrow button.
4. Press the **SET** button to enter the adjustment mode, and use the arrow buttons to select and change the values.
5. You can also change the date and time formats that are shown in the graphs. The selected formats are only used in graphical display, they do not change the formats that are used in the serial communication.
6. Press **EXIT** to return to the basic display.

### Using Serial Line

To set time enter the **TIME** command. To set date enter the **DATE** command.

**TIME**

**DATE**

These time and date settings are shown on the timestamps of **PLAY** command. When you want to include time and date in the **R** and **SEND** commands, use the **FTIME** and **FDATE** commands.

#### Example:

```
>TIME
Time           : 13:42:49 ?

>DATE
Date           : 2007-05-31 ?
```

<b>NOTE</b>	If the optional Data Logger Module is not installed, time and date are cleared to 2000-01-01 00:00:00 at reset or at power failure.
-------------	---

# User Port Serial Settings

## Using Display/Keypad

The communication settings for the user port can be changed via the serial line or by using the optional display/keypad. The communication settings for the service port are fixed and not changeable.

1. Press any of the arrow buttons to open the MAIN MENU.
2. Select **Interfaces** and press the ► arrow button to confirm your selection.
3. Select **Serial interface** and press the ► arrow button to confirm your selection.
4. Select **Bit rate/Serial format/Comm. mode** by pressing the **CHANGE** button. Use the ▲ ▼ arrow buttons to select and press **SELECT** to confirm your selection.
5. If you selected RUN communication mode, select **RUN** interval for and press **SET** to confirm your selection.
6. Use the arrow buttons to set the measuring interval and the unit. Press **OK** to confirm your settings.
7. If you selected POLL communication mode, select POLL address and press **SET** to confirm your selection.
8. Use the arrow buttons to set the transmitter address. Press **OK** to confirm the setting.
9. Use the arrow buttons to select **ECHO**. Press **ON** to turn it on. Press **OFF** to turn it off.
10. Press **EXIT** to return to the basic display.

The new user port settings set using the display/keypad are effective immediately.

## Using Serial Line

### SERI

Use the serial line command **SERI** [*b p d s*] to set communication settings for the user port.

**SERI** [*b p d s*]

where

- b = Bit rate (110, 150, 300, 600, 1200, 2400, 4800, 9600, 19200, 38400, 57600, 115200)
- p = Parity (n = none, e = even, o = odd)
- d = Data bits (7 or 8)
- s = Stop bits (1 or 2)

#### Example:

```
>SERI 600 N 8 1
600 N 8 1
>
```

You need to reset the transmitter to activate the new communication settings set with command SERI.

The settings can be changed one parameter at a time or all parameters at once:

```
>SERI O                changing parity only
4800 O 7 1
>SERI 600 N 8 1       changing all parameters
600 N 8 1
>
```

### SMODE

Use the command **SMODE** to set the user port start-up operating mode.

**SMODE** [*xxxx*]

where

*xxx* = STOP, RUN or POLL

**Table 23 Selection of Output Modes**

Mode	Output	Available Commands
STOP	Only with the <b>SEND</b> command	All (default mode)
RUN	Automatic output	Only command S
POLL	Only with the <b>SEND</b> [ <i>addr</i> ] command	Use with RS-485 buses, see Operation of the RS-485 Module on page 105.

Selected output mode will be activated after power outages.

## INTV

Use the command **INTV** to set the outputting interval for the RUN mode.

**INTV** [*xxx yyy*]

where

*xxx* = Output interval (0 ... 255). 0: the fastest possible output rate.  
*yyy* = Unit (s, min or h)

### Example:

```
>INTV 10 min
Output intrv. : 10 min
>
```

## ECHO

Use the command **ECHO** to set the user port echo. The command either enables or disables echo of characters received.

**ECHO** [*x*]

where

*x* = ON (default) or  
 = OFF

### NOTE

You can use the SERI, SMODE, INTV and ECHO commands to change/view the user port settings even if you are currently connected to the service port.

## Data Filtering

The averaging data filter calculates an average over a certain period of time. The lowest measurement noise is achieved with the extended filtering. There are three filtering levels available.

**Table 24 Filtering Levels**

Setting	Filtering level
OFF	No filtering
ON (default)	Standard = short filtering (approximately 15 s moving average)
EXTENDED	Extended filtering (default: approximately 1 min average)

Use display/keypad to set the filtering level.

1. Press any of the arrow buttons to open the **MAIN MENU**.
2. Select **Measuring** by pressing the ► arrow button.
3. Select **Filtering** and press **CHANGE** to confirm your selection.
4. Select **Off/Standard/Extended** and press **SELECT** to confirm your selection.
5. Press **EXIT** to return to the basic display.

### FILT

Use the serial line command **FILT [xxx]** to set the filtering level.

**FILT [xxx]**

where


xxx = OFF, ON or EXT (default = ON)

## Device Information

Use the display/keypad or the serial line to display the device information.

Press the **INFO** button in the basic display to see the following information:

- Current sensor operation (for example, chemical purge), if any, in progress
- Present or past unacknowledged errors, if any
- Device information
- Adjustment information fed by the user
- Measuring settings
- Information on chemical purge settings (when applicable)
- Serial interface information
- Analog output information
- Relay output information (when applicable)



0706-002

**Figure 46** Device Information on Display

Proceed in the information views by pressing the **MORE** button as many times as you get the desired information. You can browse through the information displays also with arrow buttons. Press **OK** to return to the basic display.

**?**

Use the serial line command **?** to check the current transmitter configuration. Command **??** is similar but can also be used if the transmitter is in POLL mode.

**Example:**

```
>?
HMT330 / 4.03
Serial number : B2930015
Batch number  : B2350091
Adjust. date   : 2006-07-19
Adjust. info   : Helsinki / FIN
Date           : 2007-05-30
Time           : 13:41:55
Serial mode    : STOP
Baud P D S     : 4800 E 7 1
Output interval: 0 s
Address        : 0
Echo           : ON
```

```
Pressure      : 1013.25 hPa
Filter        : OFF
Ch1 output    : 4...20mA
Ch2 output    : 4...20mA
Ch1 RH low   : 0.00 %RH
Ch1 RH high  : 100.00 %RH
Ch2 T low    : -40.00 'C
Ch2 T high   : 60.00 'C
Module 1     : LOGGER-1
Module 2     : not installed
>
```

## HELP

Use the command **HELP** to list the commands.

### Example:

```
>help
?          ACAL      ADDR      AERR      ASCL
ASEL      CDATE     CLOSE     CODE      CRH
CT        CTA       CTEXT    DATE      DELETE
DIR       DSEL      DSEND    ECHO      ERRS
FCRH      FDATE     FILT     FORM      FST
FTIME     HELP      INTV     ITEST    MODS
OPEN      PLAY      PRES     R         RESET
SEND      SERI      SMODE    TEST      TIME
UNDELETE  UNIT      VERS     XPRES
>
```

## ERRS

Use the command **ERRS** to display transmitter error messages, see Table 25 on page 120.

### Example:

```
>ERRS
NO ERRORS
>
```

### Example:

```
>ERRS
FAIL
Error: Temperature measurement malfunction
Error: Humidity sensor open circuit
>
```

## VERS

Use the command **VERS** to display software version information.

### Example:

```
>vers
HMT330 / 4.03
>
```

## Resetting Transmitter Using Serial Line

### RESET

This command resets the device. The user port switches to start-up output mode selected with command **SMODE**.

## Locking Menu/Keypad by Using Serial Line

### LOCK

Use the **LOCK** command to prevent the user from entering the menu using the keypad, or to lock the keypad completely. You can optionally set a 4-digit PIN code, for example 4444.

If a PIN code has been set, the user will be prompted to enter the code when trying to access the menu. Entering the code correctly will disable the lock until the user returns back to the basic view.

**LOCK** [x] [yyyy]

where

- x = Keypad locking level, range 0...2. The options are:
  - 0 - No lock (enables full access)
  - 1 - Menu locked, but graphs are accessible
  - 2 - Keypad completely disabled
- yyyy = 4-digit PIN code. The code can only be set when keypad locking level is 1.

**Examples:**

```
>lock 1 4444  
Keyboard lock : 1 [4444]  
>
```

```
>lock 1  
Keyboard lock : 1  
>
```

## Data Recording

Data recording function is always on and collects data automatically into the memory of the device. If the optional data logger module is installed, the transmitter uses it automatically. Recorded data does not disappear from the memory when the power is switched off. Collected data can be observed in a form of a graph in the graphical view of the display or it can be listed out by using the serial line or MI70 Link program.

## Selecting Data Recording Quantities

If the device is provided with the optional display, the recorded quantities are always those selected for the display. Up to three quantities can be recorded at a time. For instructions on how to select the display quantities with the keypad, see section Changing Quantities and Units on page 77.

### DSEL

Use the serial line command **DSEL** to select the quantities to be recorded if the transmitter is not equipped with display/keypad.

**DSEL** [xxx]

where

xxx = Data recording quantity. See Table 2 on page 15 and Table 3 on page 16 for the quantities.

**Example:**

```
>dsel rh t tdf  
RH T Tdf  
>
```

Enter the command without parameters and press **ENTER** to display the current recording parameters.

## View Recorded Data

If the device is provided with the optional display, the graphical display shows the data of the selected quantities, one at a time. See section Graphic History on page 60 for details about graphical display.

You may also dump the logged data to the serial line in numeric form with the following commands.

### DIR

Use the serial line and enter the **DIR** command to check the available files.

Without the data logger module, the device records six files (six observation periods) for each selected quantity. The data logger raises the number of recorded files to seven for each quantity. Thus, the total amount of the files varies between 6 and 21. See Table 9 on page 61.

Select, for example, three quantities (RH, T, and Tdf). The last column illustrates the number of data points that has been stored in the file.

#### Example (data logger module installed):

```
>dir
  File description           Oldest data available           No. of points
1  RH  (10 s intervals)     2007-05-30 08:26:50           13996800
2  RH  (90 s intervals)     2007-05-30 05:25:30           1555200
3  RH  (12 min intervals)   2007-05-29 05:48:00           194400
4  RH  (2 h intervals)      2007-05-19 02:00:00           19440
5  RH  (12 h intervals)     2007-03-23 12:00:00           3240
6  RH  (3 d intervals)      2006-04-20 00:00:00           540
7  RH  (12 d intervals)     2002-12-16 00:00:00           135
8  T   (10 s intervals)     2007-05-30 08:26:50           13996800
9  T   (90 s intervals)     2007-05-30 05:25:30           1555200
10 T   (12 min intervals)   2007-05-29 05:48:00           194400
11 T   (2 h intervals)      2007-05-19 02:00:00           19440
12 T   (12 h intervals)     2007-03-23 12:00:00           3240
13 T   (3 d intervals)      2006-04-20 00:00:00           540
14 T   (12 d intervals)     2002-12-16 00:00:00           135
15 Tdf (10 s intervals)     2007-05-30 08:26:50           13996800
16 Tdf (90 s intervals)     2007-05-30 05:25:30           1555200
17 Tdf (12 min intervals)   2007-05-29 05:48:00           194400
18 Tdf (2 h intervals)      2007-05-19 02:00:00           19440
19 Tdf (12 h intervals)     2007-03-23 12:00:00           3240
20 Tdf (3 d intervals)      2006-04-20 00:00:00           540
21 Tdf (12 d intervals)     2002-12-16 00:00:00           135
>
```

## PLAY

Use the **PLAY** command to output the selected file to the serial line. If the data logger module is installed, you can specify an interval to be outputted.

Data in the output is <TAB> delimited. This is compatible with most spreadsheet programs. Before giving the command, set the local date and time with **TIME** and **DATE** commands, if needed.

**PLAY** [*x*] [*start\_date start\_time end\_date end\_time*]

where

- x* = Number of the data file that will be outputted, range 0...21.  
The numbers correspond to the output of the DIR command; refer to the example on page 91.  
Selecting number 0 will output all data files.
- start\_date* = Starting date of the interval to be outputted. Must be given in the following format: yyyy-mm-dd
- start\_time* = Starting time of the interval to be outputted. Must be given in the following format: hh:mm:ss
- end\_date* = Ending date of the interval to be outputted. Must be given in the following format: yyyy-mm-dd
- end\_time* = Ending time of the interval to be outputted. Must be given in the following format: hh:mm:ss

### Example:

```
>play 3 2007-05-05 00:00:00 2007-05-06 00:00:00
RH (12 min intervals) 2007-05-05 00:00:00 121
Date      Time      trend   min     max
yyyy-mm-dd hh:mm:ss  %RH    %RH    %RH
2007-05-05 00:00:00  19.16  18.99  19.33
2007-05-05 00:12:00  19.30  19.09  19.55
2007-05-05 00:24:00  20.01  19.28  21.17
2007-05-05 00:36:00  21.21  20.98  21.44
2007-05-05 00:48:00  19.57  17.72  21.11
2007-05-05 01:00:00  19.09  18.62  19.84
...
```

The <ESC> key can be used to interrupt the output listing.

**NOTE**

Output of large amounts of recorded data can result in huge data files and take a long time, up to several days for the entire memory of the data logger at 10 second resolution. To make it easier to process the data it is recommended to select the largest suitable data interval, and to specify the start and end times carefully.

## Deleting the Recorded Files

You can delete the recorded data files using the keypad/display, or the **DELETE** command on the serial line. The deletion is always done for all data; you cannot delete individual files.

Note that the transmitter automatically overwrites the old data when the memory is full, so manual deletion of the recorded files is not necessary in normal use.

To delete the data files using the keypad/display:

1. Press any of the arrow buttons to open the **MAIN MENU**.
2. Select **System** by pressing the ► arrow button.
3. Select **Clear graph memories** by pressing the **CLEAR** button. Press the **YES** button to confirm the selection.

**CAUTION**

This function clears the entire data history of the transmitter, including all graphs and the content of the optional data logger module.

## UNDELETE

Similarly to the **DELETE** command, the **UNDELETE** command is used without any arguments. It will recover all deleted data that has not been overwritten yet.


## Analog Output Settings

The analog outputs are set in the factory according to the order form. In case you want to change the settings, follow these instructions. See section Third Analog Output on page 49.

## Changing Output Mode and Range

Both output channels have their own DIP switch module with 8 switches; see the position in Figure 2 on page 18 (DIP switches for analog output settings).

1. Select the current/voltage output; switch ON either of the switches, 1 or 2.
2. Select the range; switch ON one of the switches from 3 to 7.



**Figure 47** Current/Voltage Switches of Output Modules

The following numbers refer to Figure 47 above:

- 1 = Current/voltage selection output switches (from 1 to 2)
- 2 = Current/voltage range selection switches (from 3 to 7) in analog output 1 and 2.
- 3 = Switches for service use only. Keep in OFF position always.

### NOTE

Only one of the switches 1 or 2 must be ON at a time.

Only one of the switches 3 to 7 must be ON at a time.

**Example:** 0 ... 5 V voltage output selected for channel 1 and 4 ... 20 mA selected for channel 2.

	OFF	ON	Selection	
1	<input checked="" type="checkbox"/>	<input type="checkbox"/>	Voltage output selected	
2	<input type="checkbox"/>	<input checked="" type="checkbox"/>		
3	<input checked="" type="checkbox"/>	<input type="checkbox"/>	0 ... 5 V selected	
4	<input checked="" type="checkbox"/>	<input type="checkbox"/>		
5	<input checked="" type="checkbox"/>	<input type="checkbox"/>		
6	<input type="checkbox"/>	<input checked="" type="checkbox"/>		
7	<input checked="" type="checkbox"/>	<input type="checkbox"/>	Current output selected	
8	<input checked="" type="checkbox"/>	<input type="checkbox"/>		
1	<input type="checkbox"/>	<input checked="" type="checkbox"/>		4 ... 20 mA selected
2	<input checked="" type="checkbox"/>	<input type="checkbox"/>		
3	<input type="checkbox"/>	<input type="checkbox"/>		
4	<input type="checkbox"/>	<input checked="" type="checkbox"/>		
5	<input checked="" type="checkbox"/>	<input type="checkbox"/>		
6	<input checked="" type="checkbox"/>	<input type="checkbox"/>		
7	<input checked="" type="checkbox"/>	<input type="checkbox"/>		
8	<input checked="" type="checkbox"/>	<input type="checkbox"/>		

## NOTE

If you have customized the error output setting (**AERR**), check that the set error values are still valid after changing the output mode/range, see section Analog Output Fault Indication Setting on page 98.

## Analog Output Quantities

Use the display/keypad to change and scale the analog output quantities.

1. Press any of the arrow buttons to open the **MAIN MENU**.
2. Select **Interfaces** by pressing the ► arrow button.
3. Select **Analog outputs** by pressing the ► arrow button.
4. Select **Output 1/2/3** by pressing the ► arrow button.
5. Select **Quantity** by pressing the ▲▼ arrow buttons. Confirm your selection by pressing **CHANGE**.
6. Select the quantity by using the arrow buttons. Press **SELECT** to confirm your selection.

7. Select **Scale**, lower limit, by pressing the ▲▼ arrow buttons. Press **SET** to confirm your selection. Press **OK** to confirm your setting.
8. Select the upper limit by pressing the ▲▼ arrow buttons. Use the arrow buttons to set the upper limit value. Press **SET** to confirm your selection. Press **OK** to confirm your setting.
9. Press **EXIT** to return to the basic display.

## AMODE/ASEL

Use the serial line to select and scale the analog output quantities. Connect the transmitter to the PC. Open the terminal connection between your PC and the transmitter.

1. Check the analog output modes with the **AMODE** command.

### Example:

```
>amode
Ch1 output      : 0...1V
Ch2 output      : 0...1V
>
```

2. Select and scale the quantities for the analog outputs with the command **ASEL**. Note that the optional quantities can be selected only if they have been selected when ordering the device.

**ASEL** [xxx yyy zzz]

where

xxx = Quantity of channel 1  
yyy = Quantity of channel 2  
zzz = Quantity of the optional analog output channel 3

Enter always all the quantities for all outputs. For quantities and their abbreviations see Table 2 on page 15 and Table 3 on page 16.

Use the command **ASEL** [xxx yyy] as shown in the example below when using a device with two analog outputs.

### Example:

```
>asel rh t
Ch1 (RH ) low   : 0.00 %RH ? 0
Ch1 (RH ) high  : 100.00 %RH ? 100
Ch2 (T ) low    : -40.00 'C ? -50
Ch2 (T ) high   : 60.00 'C ? 80
>
```

## Analog Output Tests

Use the display/keypad for testing to test the operation of the analog by forcing the outputs to known values. Measure then the outputs with a current/voltage meter.

1. Press any of the arrow buttons to open the **MAIN MENU**.
2. Select **System** by pressing the ► arrow button.
3. Select **Diagnostics** by pressing the ► arrow button.
4. Select **Analog output tests** by pressing the ► arrow button.
5. Select one of the testing options **Force 0%/50%/100% of scale**. Press **TEST** to confirm your selection. All outputs are tested simultaneously. The actual output value depends on the selected range.
6. Press **OK** to stop testing. Press **EXIT** to return to the basic display.

### ITEST

Use the serial line to test the operation of the analog outputs. Use the command **ITEST** to force the analog outputs to entered values. The set values remain valid until you enter the command **ITEST** without parameters or **RESET** the transmitter.

**ITEST** [*aa.aaa bb.bbb*]

where

*aa.aaa* = Current or voltage value to be set for channel 1 (mA or V)

*bb.bbb* = Current or voltage value to be set for channel 2 (mA or V)

#### Example:

```
>itest 20 5
Ch1 (Td )      :          *          20.000 mA   H'672A
Ch2 (T )       :          *           5.000 mA   H'34F9
>itest
Ch1 (Td )      :   -23.204 'C       16.238 mA   H'FFFE
Ch2 (T )       :    22.889 'C        8.573 mA   H'5950
>
```

## Analog Output Fault Indication Setting

Factory default state for analog outputs during error condition is 0 V/0 mA. Please be careful when selecting the new error value. The error state of the transmitter should not cause unexpected problems in process monitoring.

Use the display/keypad to set the analog output fault indication.

1. Press any of the arrow buttons to open the **MAIN MENU**.
2. Select **Interfaces** by pressing the ► arrow button.
3. Select **Analog Outputs** by pressing the ► arrow button.
4. Select **Output 1/2/3** by pressing the ► arrow button.
5. Select Fault indication. Press **SET** to confirm your selection. Enter the fault indication value by using the arrow buttons. Press **OK** to confirm your setting. This value is outputted if a transmitter error occurs.
6. Press **EXIT** to return to the basic display.

### AERR

Use the serial line **AERR** command to change the error output.

#### AERR

##### Example:

```
>aerr
Ch1 error out : 0.000V ? 5.0
Ch2 error out : 0.000V ? 5.0
>
```

**NOTE**

The error output value must be within a valid range of the output mode.

**NOTE**

The error output value is displayed only when there are minor electrical faults such as humidity sensor damage. When there is a severe device malfunction, the error output value is not necessarily shown.

# Operation of Relays


## Quantity for Relay Output

A relay monitors the quantity chosen for the relay output. Any of the quantities available can be chosen.

## Measurement-Based Relay Output Modes

### Relay Setpoints

When the measured value is in between the "above" and "below" values, the relay is passive. When choosing lower value as "above" value and higher value as "below" value, the relay is passive when the measured value is not between the setpoints. You can also set only one setpoint. See Figure 48 below for illustrative examples of the different measurement-based relay output modes.



0610-076

**Figure 48** Measurement-Based Relay Output Modes

Mode 4 is usually used if an alarm needs to be triggered when the measured value exceeds a safe range. The relay is active when measurement is in range, and is released if the value goes out of range or the measurement fails.

**NOTE**

If the measurement of the selected quantity fails or the transmitter loses its power, the relay is released.

## Hysteresis

Hysteresis function is to prevent the relay switching back and forth when the measured value is near to the setpoint values.

Relay is activated when the measured value passes the exact value of the setpoint. When returning and passing the setpoint again relay is not released before the value reaches the setpoint increased/decreased by the hysteresis value.

Hysteresis should be smaller than difference of the setpoints.

**Example:** When the 'active above' value is 60 %RH and the hysteresis value is 5 %RH, relay activates when the relative humidity reaches 60 %RH. As the humidity decreases, relay releases at 55 %RH.

**NOTE**

If both setpoints are specified and "above" setpoint is lower than "below" setpoint, the hysteresis works in the opposite direction, that is, relay is **released** when the measured value passes the exact value of the setpoint.

## Relay Indicating Transmitter Error Status

You can set a relay to follow the operation status of the device. By selecting FAULT/ONLINE STATUS for output quantity a relay changes state on the basis of the operation status as follows:

### FAULT STATUS

Normal operation: relay active (C and NO outputs are closed)


Not measuring state (error state or power off): relay released (C and NC outputs are closed)

### ONLINE STATUS

Live measurement (data available): relay active (C and NO outputs are closed)

No live data (for example: error state, chemical purge or adjustment mode): relay released (C and NC outputs are closed)

See Figure 49 below for illustrative examples of the FAULT/ONLINE STATUS relay output modes.



**Figure 49** FAULT/ONLINE STATUS Relay Output Modes

FAULT/ONLINE STATUS relays are usually used in conjunction with an analog output to obtain validity information for the output value.

#### **NOTE**

If transmitter loses its power, all status-based relays are released similarly to the case of an instrument failure.

## Enabling/Disabling Relays


You can deactivate the relay outputs for example for service purposes of your system.

## Setting Relay Outputs

### NOTE

When having only one relay module installed, its relays are called 'relay 1' and 'relay 2'.

When having two relay modules, the relays of the module connected to slot **MODULE 1** are called 'relay 1' and relay 2' and relays connected to slot **MODULE 2** are called 'relay 3' and 'relay 4'



0706-003

**Figure 50** Relay Indicators on Display

The following number refers to Figure 50 above:

- 1 = Lists enabled relays. Activation state shown in black.  
Disabled relays are not shown.

Use the display/keypad to set the relay outputs.

1. Press any of the arrow buttons to open the **MAIN MENU**.
2. Select **Interfaces**, confirm by pressing the ► arrow button.
3. Select **Relay outputs**, confirm by pressing the ► arrow button.
4. Select **Relay 1/2/3/4**, confirm by pressing the ► arrow button.
5. Select the **Quantity**, confirm by pressing **Change**. Select the Quantity by using the arrow buttons. Confirm your selection by pressing **Select**.
6. Select **Act. above / Act. below**. Press **SET** to confirm your selection. (If asked, select **MODIFY** if you want to set the setpoint by using the arrow buttons. Select **REMOVE** if you want to remove the setpoint.)

7. Select **Hysteresis** by using the arrow buttons. Press **SET** to set the hysteresis. Press **OK**.
8. Select **Relay enable** by using the arrow buttons, press **ON/OFF** to enable/disable the relay.

## RSEL

Use the serial line to select the quantity, setpoints and hysteresis or enable/disable the relay outputs. Enter the **RSEL** command.

### RSEL [*q1 q2 q3 q4*]

where

- q1* = quantity for the relay 1 or Fault/Online
- q2* = quantity for the relay 2 or Fault/Online
- q3* = quantity for the relay 3 or Fault/Online
- q4* = quantity for the relay 4 or Fault/Online

Factory setting: all relays disabled.

Use the quantity abbreviations presented above. See Table 2 on page 15 and Table 3 on page 16.

**Example of window limit switch:** Selecting relay 1 to follow dewpoint/frost point temperature measurement and relay 2 to follow temperature measurement. Two relay setpoints are set for both relays.

```
>rsel rh t
Rel1 RH  above: 0.00 %RH ? 30
Rel1 RH  below: 0.00 %RH ? 40
Rel1 RH  hyst : 0.00 %RH ? 2
Rel1 RH  enabl: OFF ? ON
Rel2 T   above: 0.00 'C ? 30
Rel2 T   below: 0.00 'C ? 40
Rel2 T   hyst : 0.00 'C ? 3
Rel2 T   enabl: OFF ? ON
>
```

**Example of normal limit switch:** Selecting relay 1 to follow relative humidity, relay 2 to follow temperature, relay 3 to follow dewpoint and relay 4 to follow dewpoint. One setpoint is chosen for all the outputs.

```
>rsel rh t td td
Rel1 RH   above: 60.00 %RH ? 70
Rel1 RH   below: 70.00 %RH ? -
Rel1 RH   hyst : 2.00 %RH ? 2
Rel1 RH   enabl: ON ? on
Rel2 T    above: 50.00 'C ? 60
Rel2 T    below: 40.00 'C ? -
Rel2 T    hyst : 2.00 'C ? 2
Rel2 T    enabl: ON ? on
Rel3 Td   above: 5.00 'C ? 10
Rel3 Td   below: 0.00 'C ? -
Rel3 Td   hyst : 1.00 'C ? 1
Rel3 Td   enabl: OFF ? on
Rel4 Td   above: 0.00 'C ? 20
Rel4 Td   below: 0.00 'C ? -
Rel4 Td   hyst : 0.00 'C ? 2
Rel4 Td   enabl: OFF ? on
>
```

**Example of using relay 1 as fault alarm:** selecting relay 1 to follow the fault status and relay 2 to follow the temperature measurement.

```
>rsel fault t
Rel1 FAUL above: -
Rel1 FAUL below: -
Rel1 FAUL hyst : -
Rel1 FAUL enabl: ON ?
Rel2 T    above: 0.00 'C ? 30
Rel2 T    below: 0.00 'C ? -
Rel2 T    hyst : 0.00 'C ? 2
Rel2 T    enabl: OFF ? ON
>
```

## Testing Operation of Relays

Testing activates relays even if they are disabled.

Use the module push buttons to activate the relays. Press the **REL 1** or **REL 2** button to activate the corresponding relay.

Relay is activated:	led is lit
Relay is not activated:	led is not lit

Use the display/keypad to test the operation of relays.

1. Open the **MAIN MENU** by pressing any of the arrow buttons.
2. Select **System**, press the ► arrow button.
3. Select **Diagnostics**, press the ► arrow button.
4. Select **Relay tests**, press the ► arrow button.
5. Select **Invert relay 1...**, press **TEST**. Now the selected relay output is forced to opposite state. Press **OK** to return to normal operation.
6. Press **EXIT** to return to the basic display.

## RTEST

Use the serial line command **RTEST** to test the operation of the relays.

**RTEST** [*x1 x2 x3 x4*]

where

x = ON/OFF

**Example:** Activate and then release all four relays.

```
>rtest on on on on
  ON ON ON ON
>
>rtest off off off off
  OFF OFF OFF OFF
>
```

Enter the command **RTEST** without parameters to stop testing.

## Operation of the RS-485 Module

The RS-485 interface enables communication between RS-485 network and HMT330 transmitter. The RS-485 interface is isolated and offers a maximum communications rate of 115 200 bits/s. (For maximum bus length of 1 km, use bit rate 19200 b/s or less.)

When selecting an RS-232-RS-485 converter for the network, avoid self powered converters as they don't necessarily support the needed power consumption.

Echo function shall be always disabled (OFF) when using the 2-wire connection. When using the 4-wire connection you can disable/enable the echo setting.

**NOTE**

User port on HMT330 main board cannot be used and connected when RS-485 module is connected. Service port is operating normally.

## Networking Commands

Set the RS-422/485 interface by using the following commands. The other serial line commands are presented in section List of Serial Commands on page 72.

RS-485 configuration commands **SERI**; **ECHO**; **SMODE**; **INTV** and **ADDR** may be entered by using either the service port or RS-422/485 port. Also the optional display/keypad can be used, see section User Port Serial Settings on page 83.

### SDELAY

With the **SDELAY** command you can set delay (response time) for user port (RS232 or RS485), or view currently set delay value. Value corresponds to tens of milliseconds (eg. 5 = 0.050s minimum answer delay). The value can be set between 0...254.

**Example:**

```
>sdelay
Serial delay   : 0 ? 10

>sdelay
Serial delay   : 10 ?
```

### SERI

Use the **SERI** command to input RS-485 bus settings.

**SERI** [*b p d s*]

where

where

- $b$  = bit rate (300, 600, 1200, 2400, 4800, 9600, 19200, 38400, 57600, 115200)
- $p$  = parity (n = none, e = even, o = odd)
- $d$  = data bits (7 or 8)
- $s$  = stop bits (1 or 2)

## ECHO

Use the **ECHO** command to enable/disable echo of characters received over the serial line.

### **ECHO** [ $x$ ]

where

- $x$  = ON/OFF (default = OFF)

When using 2-wire connection, echo must be always disabled.

## SMODE

Use the **SMODE** command to set the default serial interface mode.

### **SMODE** [ $xxxx$ ]

where

$xxxx$  = STOP, RUN or POLL

In STOP mode: measurements output only by command SEND, all commands can be used

In RUN mode: outputting automatically, only command S can be used to stop.

In POLL mode: measurements output only with command SEND [ $addr$ ].

When several transmitters are connected to the same line, each transmitter must be entered an own address in the initial configuration, and POLL mode must be used.

## INTV

Use the **INTV** command to set the RUN mode output interval.

**INTV** [*n xxx*]

where

*n* = 1 - 255  
*xxx* = S, MIN or H

This command sets the RUN mode output interval. The time interval is used only when the RUN mode is active. For example, the output interval is set to 10 minutes.

```
>INTV 10 min
Output intrv. : 10 min
>
```

Setting RUN output interval to zero enables the fastest possible output rate.

## ADDR

Addresses are required only for POLL mode (see serial line command SMODE on page 84). Use the **ADDR** command to input the RS-485 transmitter address.

**OPEN** [*aa*]

where

*aa* = address (0 ... 99) (default = 0)

**Example:** the transmitter is configured to address 99.

```
>ADDR
Address : 2 ? 99
>
```

## SEND

Use the SEND command to output the reading once in POLL mode:

**SEND** [*aa*]

where

*aa* = address of the transmitter

## OPEN

When all transmitters on the RS-485 bus are in POLL mode the **OPEN** command sets one transmitter temporarily to STOP mode so that other commands can be entered.

**OPEN** [*aa*]

where

*aa* = address of the transmitter (0 ... 99)

## CLOSE

The **CLOSE** command switches the transmitter back to the POLL mode.

### Example:

```
>OPEN 2 (opens the line to transmitter 2, other  
transmitters stay in POLL mode)  
>CRH (for example, calibration performed)  
...  
>CLOSE (line closed)
```


# Sensor Functions

## Chemical Purge (Optional)

In some specific applications the sensor gain may decrease gradually due to an interference caused by a particular chemical present in the measured gas, for example. The decrease of sensor gain due to an interfering chemical and the effect of the chemical purge process are illustrated below, see Figure 51 below. The sensor polymer absorbs the interfering chemical; and this reduces the ability of the polymer to absorb water molecules and consequently the sensor gain decreases. In chemical purge, heating the humidity sensor to a temperature level of approximately +160 °C for several minutes evaporates the interfering chemical.

The purge function starts with heating stage, continues with settling and when the temperature of the sensor is decreased the transmitter returns to normal mode. The whole cycle takes about 6 minutes.

**NOTE** Chemical purge function locks the output values for about 6 minutes.



0508-035

**Figure 51** Decrease of Sensor Gain

Before starting the chemical purge note the following:

- The sensor is protected with a PPS grid with stainless steel netting, a stainless steel sintered filter or with membrane SST filter.
- The sensor temperature must be below 100 °C. At higher temperatures the chemicals evaporate spontaneously from the sensor and the chemical purge is not necessary.

### **Automatic Chemical Purge (Interval Purge)**

When HMT330 leaves the factory the automatic chemical purge (if chosen) takes place repeatedly with the time intervals set in the factory. User can change the interval in which the purge takes place by using serial commands or with the optional display/keypad. This can be needed if the measuring environment contains high concentrations of interfering chemicals. The automatic chemical purge can also be turned off if necessary.

### **Manual Chemical Purge**

The chemical purge should be performed always before calibration (see section Calibration and Adjustment on page 123) or when there is a reason to believe that a sensor has become exposed to an interfering chemical. Make sure that the temperature of the sensor has come down to normal temperature before starting a calibration.

### **Chemical Purge in Power Up**

Chemical purge (start-up purge) can be set to start within 10 seconds from the power-up of the device.

# Starting and Configuring Chemical Purge

## Using Buttons on Motherboard

Start manual chemical purge by pressing simultaneously two PURGE buttons on the motherboard inside the transmitter for a few seconds. Indicator led flashes until purge is complete (up to 6 minutes).




Figure 52 Purge Buttons on Motherboard

## Using Display/Keypad (Optional)

Set the automatic and manual chemical purge by using the display/keypad.

1. Open the MAIN MENU by pressing any of the ▼ ▲ ◀ ▶ arrow buttons.
2. Select ► Measuring, press ► button.
3. Select ► Chemical purge, press ► button.





Figure 53 Chemical Purge Settings

- Turn on/off the automatic purge by selecting **Automatic purge**, press ► **ON/OFF** button.
  - Set the automatic purge interval by selecting **Interval: ...**, press **SET**. Set the purge interval and the unit (hour/day) by using the arrow buttons. The interval must be 1 hour ... 10 days. Press **OK**.
  - Select **Start-up purge** by using the arrow buttons. Press On/Off to turn the start-up purge on/off.
  - Start manual purge by selecting **Manual purge** and pressing **START**.
4. Press **EXIT** to return to the basic display.



**Figure 54** Performing Chemical Purge

## Using Serial Line

### PURGE

Enter the **PURGE** command to start chemical purge immediately.

```
>purge
Purge started, press any key to abort.
>
```

The prompt '>' appears when the heating period is over. However, the transmitter outputs are locked to the values measured before performing chemical purge until the settling time is over.

With **PUR** command you can enable or disable automatic and power-up chemical purge and set the interval for automatic purge. If the sensor is exposed to chemicals it is recommended to have the chemical purge done at least once in 720 min (=12 hours). In applications where the chemical exposure is not likely, the interval can be longer.

It is not recommended to change duration, settling, temperature or temperature difference.

## PUR

Type **PUR** and press ENTER to proceed. The maximum interval is 14400 minutes (=10 days).

### Example:

```
>pur
Interval Purge : OFF ?
Interval       : 720 min ?
Power-up Purge : OFF ?
Duration      : 120 s ?
Settling      : 240 s ?
Temperature   : 160 'C ?
Temp. diff.   : 0.5 'C ?
>
```

**NOTE**

To activate the new interval settings immediately, reset the transmitter.

**NOTE**

When chemical purge in power-up is enabled, wait about 6 min after power-up before taking measurements. The output channels are locked for the first operation minutes to the initial measured values

## Sensor Heating

This function is optionally available only in transmitters with HUMICAP®180C or HUMICAP®180RC sensor. It should be used only with the warmed probe.

The sensor heating is recommended for the high humidity environments where even a small temperature differences can cause water to condense on the sensor. The sensor heating speeds up the recovery of the humidity sensor from condensation.

Sensor heating starts-up when the relative humidity of the measuring environment reaches the RH-value set by a user (RH-limit). The user can define the RH-sensor heating temperature as well as the duration of the heating.

After the heating cycle the humidity conditions are checked and new sensor heating is performed if the predefined conditions are reached again.

**NOTE**

During the sensor heating the outputs are locked to the values measured before the heating cycle.

## Setting Humidity Sensor Heating

When the HMT330 leaves the factory the sensor heating follows the factory default values. You can enable/disable the function, change the RH-limit and define the heating temperature and duration of this function.

### XHEAT

Enables/disables the sensor heating.

### XHEAT [xx]

where:

xx = ON / OFF

```
>xheat on
Extra heat      : ON
>xheat off
Extra heat      : OFF
>
```

To configure the sensor heating use the XHEAT command without parameters. Enter the values after question mark. The available ranges include the following:

Extra heat RH -limit (heating function starts-up above the setpoint)	0 ... 100 %RH (default: 95 %RH)
Extra heating temperature	0 ... 200 °C (default: 100 °C)
Extra heating time	0 ... 255 s (default: 30 s)

**Example:**

```
>xheat
Extra heat      : OFF
Extra heat RH  : 95 ? 90
Extra heat temp: 100 ? 85
Extra heat time: 30 ? 10
>xheat on
Extra heat      : ON
>
```

## CHAPTER 5

# MAINTENANCE

This chapter contains information that is needed in basic maintenance of the product.

## Periodic Maintenance

### Cleaning

Clean the transmitter enclosure with a soft, lint-free cloth moistened with mild detergent.

### Changing the Probe Filter


1. Remove the filter from the probe.
2. Install a new filter on the probe. When using the stainless steel filter (for oil and fuel cell), take care to tighten the filter properly (recommended force 5 N).

New filters can be ordered from Vaisala, see section Options and Accessories on page 141.

## Changing the Sensor

The user can change the HUMICAP180, HUMICAP180L, and HUMICAP180R sensors.

1. Remove the filter from the probe. See the instructions in section Changing the Probe Filter on page 117.
2. Remove the damaged sensor and insert a new one. Handle the new sensor by the plastic socket. **DO NOT TOUCH THE SENSOR PLATE.**
3. After sensor change the humidity calibration must be made according to the instructions, see section Relative Humidity Adjustment after Sensor Change on page 128.
4. Attach a new filter on the probe. When using the stainless steel filter, take care to tighten the filter properly (recommended force 5 N).



**Figure 55** Changing the Sensor


The following numbers refer to Figure 55 above:

- 1 = Pull out the sensor
- 2 = Plastic socket

## Error States

In error state the quantity is not measured and the output is shown as follows:

- Analog channel outputs 0 mA or 0 V (you can use the serial line command **AERR** or display/keypad to change this fault indication value, see section Analog Output Fault Indication Setting on page 98.)
- The serial port outputs stars (\*\*\*)
- The cover LED is blinking
- Optional display: error indicator is lit.



0706-008

**Figure 56 Error Indicator and Error Message**

The following number refers to Figure 56 above:

1 = Error Indicator

- The error indicator disappears when the error state is over and you have checked the error message. Press the **INFO** button to display the error message.

You can also check the error message via the serial interface by using the command **ERRS**. In case of constant error, please contact Vaisala, see Vaisala Service Centers on page 122.

**Table 25 Error Messages**

<b>Error Message</b>	<b>Action</b>
Humidity sensor measurement malfunction.	Check the integrity of the humidity probe and the probe cable. Clean the probe from dirt, water, ice or other contaminants.
Humidity sensor short circuit	Check the integrity of the humidity probe and the probe cable. Clean the probe from dirt, water, ice or other contaminants.
Humidity sensor open circuit	Check the integrity of the humidity probe and the probe cable.
Temperature sensor open circuit.	Check the integrity of the humidity probe and the probe cable.
Temperature sensor short circuit.	Check the integrity of the humidity probe and the probe cable. Clean the probe from dirt water, ice or other contaminants.
Temperature measurement malfunction	Check the integrity of the humidity probe and the probe cable. Clean the probe from dirt water, ice or other contaminants.
Temperature sensor current leak.	Check the integrity of the humidity probe and the probe cables. Clean the probes from dirt, water, ice or other contaminants.
Internal ADC read error	Internal transmitter failure. Remove the transmitter and return the faulty unit to Vaisala Service.
Internal EEPROM read error	Internal transmitter failure. Remove the transmitter and return the faulty unit to Vaisala Service.
Internal EEPROM write error	Internal transmitter failure. Remove the transmitter and return the faulty unit to Vaisala Service.
Add-on module 1 (or 2) connection failure	Turn off the power and check the module connection. Turn on the power.
Device internal temperature out of range	Ensure that the operating temperature is within the valid range.
Operating voltage out of range	Ensure that the operating voltage is within the valid range.
Internal analog voltage out of range	Internal transmitter failure. Remove the transmitter and return the faulty unit to Vaisala Service.
Internal system voltage out of range	Internal transmitter failure. Remove the transmitter and return the faulty unit to Vaisala Service.
Internal ADC reference voltage out of range	Internal transmitter failure. Remove the transmitter and return the faulty unit to Vaisala Service.
Internal analog output reference voltage out of range	Internal transmitter failure. Remove the transmitter and return the faulty unit to Vaisala Service.
Configuration switches for analog output 1/2/3 set incorrectly	Check and re-set the switches, see page 55.
EEPROM failure on add-on module 1 (or 2)	Disconnect the power and check the analog output module connection.
Communication module installed in incorrect add-on module slot	Disconnect the power and change the communication module to another module slot.
Unknown/incompatible module installed in add-on module slot 1(or 2)	Ensure that the module is compatible with the HMT330.

## Technical Support

For technical questions, contact the Vaisala technical support:

E-mail [helpdesk@vaisala.com](mailto:helpdesk@vaisala.com)

Fax +358 9 8949 2790

## Return Instructions

If the product needs repair, please follow the instructions below to speed up the process and to avoid extra costs to you.

1. Read the section Warranty on page 13.
2. Contact a Vaisala Service Center or a local Vaisala representative. The latest contact information and instructions are available from [www.vaisala.com](http://www.vaisala.com). Addresses of the Service Centers are provided in section Vaisala Service Centers on page 122.

Please have the following information on hand:

- serial number of the unit
  - date and place of purchase or last calibration
  - description of the fault
  - circumstances in which the fault occurs/occurred
  - name and contact information of a technically competent person who can provide further information on the problem
3. Pack the faulty product in a strong box of adequate size, with proper cushioning material to avoid damage.
  4. Include the information specified in step 2 in the box with the faulty product. Also include a detailed return address.
  5. Ship the box to the address specified by your Vaisala contact.

## Vaisala Service Centers

Vaisala Service Centers perform calibrations and adjustments as well as repair and spare part services. See contact information below.

Vaisala Service Centers also offer accredited calibrations, maintenance contracts, and a calibration reminder program. Do not hesitate to contact them to get further information.

### **NORTH AMERICAN SERVICE CENTER**

**Vaisala Inc.**, 10-D Gill Street, Woburn, MA 01801-1068, USA.

Phone: +1 781 933 4500, Fax: +1 781 933 8029

E-mail: [us-customersupport@vaisala.com](mailto:us-customersupport@vaisala.com)

### **EUROPEAN SERVICE CENTER**

**Vaisala Instruments Service**, Vanha Nurmijärventie 21 FIN-01670 Vantaa, FINLAND.

Phone: +358 9 8949 2658, Fax: +358 9 8949 2295

E-mail: [instruments.service@vaisala.com](mailto:instruments.service@vaisala.com)

### **TOKYO SERVICE CENTER**

**Vaisala KK**, 42 Kagurazaka 6-Chome, Shinjuku-Ku, Tokyo 162-0825, JAPAN.

Phone: +81 3 3266 9617, Fax: +81 3 3266 9655

E-mail: [aftersales.asia@vaisala.com](mailto:aftersales.asia@vaisala.com)

### **BEIJING SERVICE CENTER**

**Vaisala China Ltd.**, Floor 2 EAS Building, No. 21 Xiao Yun Road, Dongsanhuan Beilu, Chaoyang District, Beijing, P.R. CHINA 100027.

Phone: +86 10 8526 1199, Fax: +86 10 8526 1155

E-mail: [china.service@vaisala.com](mailto:china.service@vaisala.com)

**[www.vaisala.com](http://www.vaisala.com)**

## CHAPTER 6

# CALIBRATION AND ADJUSTMENT

The HMT330 is fully calibrated and adjusted as shipped from factory. Typical calibration interval is one year. Depending on the application it may be good to make more frequent checks. Calibration must be done always when there is a reason to believe that the device is not within the accuracy specifications.


It is recommended that calibration and adjustment should be carried out by Vaisala. See section Vaisala Service Centers on page 122.

Calibration and adjustment is carried out either by using the push-keys on the motherboard, through the serial port or with the optional display/keypad.

(Vaisala portable instruments HM70 and HMI41 can also be used).

## Opening and Closing the Adjustment Mode

1. Open the transmitter cover. The buttons needed in adjustment are on the left-hand side of the motherboard.
2. If the chemical purge option is available, it should be carried out always before calibration. To start chemical purge press simultaneously two **PURGE** push-keys (on the motherboard) for a few seconds. Red indicator led flashes with short pulses until purge is complete (up to 6 minutes).
3. Press the **ADJ** key to open the adjustment mode.
4. Press the **ADJ** key again to close the adjustment mode.



**Figure 57 Adjustment and Purge Buttons**

The following numbers refer to Figure 57 above:

- 1 = Indicator led
- 2 = Adjustment button
- 3 = Press the purge buttons simultaneously to start chemical purge (if available)

Adjustment menu is displayed only when **ADJ** button (on the motherboard inside the transmitter) is pressed.



**Figure 58 Adjustment Menu**

**Table 26 Indicator Led Functions**

Indicator Led Function	Description
LED off	adjustment locked
LED on	adjustment available
LED blinking evenly	measurement not stabilized
LED blinking with short pulses	performing chemical purge

**NOTE**

If using a warmed probe (**HMT337 option**), probe heating will be interrupted when **ADJ** key is pressed. Allow sufficient time for the probe to reach ambient temperature before starting the adjustment procedure.

**NOTE**

Fixed pressure compensation value of 1013.25 hPa is used when in adjustment mode

## Relative Humidity Adjustment

### Using Push-Buttons

A simple push-button adjustment is carried out by using two relative humidity references: 11 % RH (LiCl) and 75 % RH (NaCl).

1. Carry out the chemical purge (if available).

#### LiCl reference

2. Press the **ADJ** button (see Figure 57 on page 124) on the motherboard to open the adjustment mode. The indicator led starts flashing.
3. Remove the filter from the probe and insert the probe into a measurement hole of the 11 % RH (LiCl) in the humidity calibrator HMK15. Use the adapter fitting for the probes of HMT334, HMT335, HMT337 and HMT338.
4. Wait at least 30 minutes for the sensor to stabilize (the indicator led is lit continuously). Adjustment cannot be done if the conditions are not stabilized (indicator led is flashing).
5. When the indicator led is lit continuously, press the button LiCl-11% to adjust the 11 % RH condition. After adjustment transmitter returns to normal operation mode (indicator led is unlit).

#### NaCl reference


6. When adjusting in the second reference 75 % RH, press the **ADJ** button to open the adjustment mode. The indicator led starts flashing.
7. Insert the probe into a measurement hole of the 75 % RH (NaCl) reference chamber of the humidity calibrator HMK15. Use the adapter fitting for the probes of HMT334, HMT335, HMT337 and HMT338.
8. Wait at least 30 minutes for the sensor to stabilize (the indicator led is lit continuously). Adjustment cannot be done if the conditions are not stabilized (indicator led is flashing).

9. Press the button **NaCl 75 %** to adjust the 75 % RH condition. After adjustment transmitter returns to normal operation mode (indicator led is unlit).

## Using Display/Keypad

Note that the difference between the two humidity references must be at least 50% RH.

1. Carry out the chemical purge (if available).
2. Press the **ADJ** button (opens the **ADJUSTMENT MENU**).
3. Select **Adjust RH measurement**, press **▶** button.
4. Select **1-point/ 2-point adjustment**, press. Press **START**.
5. Select the reference as guided by the display, press **SELECT**.



0706-005

**Figure 59** Selecting Point 1 Reference Type

6. Remove the filter from the probe and insert the probe into a measurement hole of the dry end reference chamber (for example, LiCl: 11 % RH in the humidity calibrator HMK15.) Use the adapter fitting for the probes of HMT334, HMT335, HMT337 and HMT338.
7. Wait at least 30 minutes for the sensor to stabilize. Follow the stabilization from the **GRAPH** display.
8. Press **READY** when stabilized. If you have chosen the **Other** reference value, enter now the reference value by using the arrow buttons.  
  
When carrying out the 2-point adjustment proceed to the next adjustment point and carry out the procedure as described in the previous items.
9. Answer **YES** to confirm the adjustment. Press **OK** to return to the adjustment menu.
10. Press **EXIT** to close the adjustment mode and return to the basic display. Before closing the adjustment mode, feed the

adjustment information into the device, see section Feeding Adjustment Information on page 132.

## Using Serial Line

Note that the difference between the two humidity references must be at least 50% RH.

1. Connect the HMT330 to a PC. See section Serial Line Communication on page 66. Open a terminal program.
2. Carry out the chemical purge (if available).
3. Press the **ADJ** button.
4. Remove the filter from the probe and insert the probe into a measurement hole of the dry end reference chamber (for example, LiCl: 11 % RH in the humidity calibrator HMK15). Use the adapter fitting for the probes of HMT334, HMT335, HMT337 and HMT338.
5. Enter the **CRH** command and press **ENTER**.

### CRH

6. Wait at least 30 minutes for the sensor to stabilize.
7. Type **C** and press **ENTER** a few times to check if the reading is stabilized.
8. When the reading is stabilized, give the reference humidity after the question mark and press **ENTER**.

```
>crh
```

```
RH :    11.25  Ref1 ? c
RH :    11.25  Ref1 ? c
RH :    11.25  Ref1 ? c
RH :    11.24  Ref1 ? c
RH :    11.24  Ref1 ? 11.3
Press any key when ready ...
```

9. Now the device is waiting for the high end reference. Insert the probe into the measurement hole of the high end reference chamber (for example, NaCl: 75 % RH chamber in the humidity calibrator HMK15). Use the adapter fitting for the HMT334, HMT335, HMT337 and HMT338 probes. Press any key when ready.
10. Let the probe stabilize for about 30 minutes. You can follow the stabilization by typing **C** and pressing **ENTER**.

11. When stabilized, type the high end reference value after the question mark and press **ENTER**.

```
>crh
```

```
RH : 11.25 Ref1 ? c  
RH : 11.24 Ref1 ? c  
RH : 11.24 Ref1 ? 11.3  
Press any key when ready ...
```

```
RH : 75.45 Ref2 ? c  
RH : 75.57 Ref2 ? c  
RH : 75.55 Ref2 ? c  
RH : 75.59 Ref2 ? 75.5
```

```
OK
```

```
>
```

12. **OK** indicates that the adjustment has succeeded and the new calibration coefficients are calculated and stored. Enter the adjustment information (date and text) to the memory of the transmitter; see the commands **CTEXT** and **CDATE**.
13. Press the **ADJ** button on the motherboard to close the adjustment mode.
14. Take the probe out of the reference conditions and replace the filter.

## Relative Humidity Adjustment after Sensor Change

### Using Display/Keypad

When using the optional display/keypad, follow the instructions on Using Display/Keypad on page 126 but select **Adj. for new RH sensor** (instead of **1-point/ 2-point adjustment**).

### Using Serial Line

After sensor change, carry out the procedure as described in previous sections. Just replace the **CRH** command with the **FCRH** command.

## FCRH

### Example:

```
>FCRH
RH   :   1.82 1. ref   ?   0
Press any key when ready...
RH   :   74.22   2. ref   ? 75
OK
>
```

The OK indicates that the calibration has succeeded.

# Temperature Adjustment

## Using Display/Keypad

1. Press the **ADJ** button on the motherboard to open the **ADJUSTMENT MENU**. If using a warmed probe for measuring, probe heating will be interrupted when **ADJ** key is pressed. Wait some time for the probe to reach ambient temperature.
2. Select **► Adjust T measurement**, press **►** key.
3. Select **1-point/ 2-point adjustment**, press. Press **START**.
4. Remove the filter from the probe and insert the probe into the reference temperature.
5. Wait at least 30 minutes for the sensor to stabilize. Follow the stabilization from the **GRAPH** display.
6. Press **READY** when stabilized. Give the reference temperature by using the arrow buttons.

When carrying out the 2-point adjustment proceed to the next adjustment point and carry out the procedure as described in the previous item. Please, note that the difference between the two temperature references must be at least 30 °C.

7. Press **OK**. Press **YES** to confirm the adjustment.
8. Press **OK** to return to the adjustment menu.
9. Press **EXIT** to close the adjustment mode and return to the basic display.

## Using Serial Line

1. Press the **ADJ** key on the motherboard to open the adjustment mode. If using a warmed probe for measuring, probe heating will be interrupted when **ADJ** key is pressed. Wait some time for the probe to reach ambient temperature.
2. Remove the probe filter and insert the probe into the reference temperature.
3. Enter the command **CT** or (**CTA** for additional T probe) and press **ENTER**.

### **CT**

or for additional T probe:

### **CTA**

4. Type **C** and press **ENTER** a few times to check if the reading is stabilized. Let the reading stabilize, give the reference temperature after the question mark and press **ENTER** three times.

When using two reference temperatures (2-point calibration) press **ENTER** only twice and insert the probe to the second reference. When the reading is stabilized, give the second reference temperature after the question mark and press **ENTER**. Please, note that the difference between the two temperature references must be at least 30 °C.

Example (1-point adjustment):

```
>ct
T :    16.06  Ref1 ? c
T :    16.06  Ref1 ? 16.0
Press any key when ready ...
T :    16.06  Ref2 ?
OK
>
```

5. **OK** indicates that the calibration has succeeded. Enter the calibration information (date and text) to the transmitter's memory; see the serial commands **CTEXT** and **CDATE**.
6. Press the **ADJ** button on the motherboard to close the adjustment mode.

7. Take the probe out of the reference conditions and replace the filter.

## Analog Output Adjustment

In the analog output calibration the analog output is forced to the following values:

- Current output: 2 mA and 18 mA
- Voltage output: 10 % and 90 % of the range

Connect HMT330 to a calibrated current/voltage meter in order to measure either current or voltage depending on the selected output type.

## Using Display/Keypad

1. Press the **ADJ** button to open the **ADJUSTMENT MENU**.
2. Select **Adjust analog outputs**, press **►** button.
3. Select the output to be adjusted **Adjust analog output 1/2**, press **START**.
4. Measure the first analog output value with a multimeter. Give the measured value by using the arrow buttons. Press **OK**.
5. Measure the second analog output value with a multimeter. Give the measured value by using the arrow buttons. Press **OK**.
6. Press **OK** to return to the adjustment menu.
7. Press **EXIT** to close the adjustment mode and to return to the basic display.

## Using Serial Line

Enter the **ACAL** command and type the multimeter reading for each case. Continue by pressing **ENTER**.

### ACAL

Example (current outputs):

```
>ACAL
Ch1 I1 (mA) ? 2.046
Ch1 I2 (mA) ? 18.087
```

```
Ch2 I1 (mA) ? 2.036
Ch2 I2 (mA) ? 18.071
>
```

## Feeding Adjustment Information

This information is shown on the device information fields (see section Device Information on page 86.)

## Using Display/Keypad

1. If you are not in the adjustment menu, press the **ADJ** button on the motherboard (opens the **ADJUSTMENT MENU**).
2. Select **Adjustment info**, press the **▶** button.
3. Select **Date**, press **SET**. Give the date by using the arrow buttons. Press **OK**.
4. Select **i**, press **SET**. Enter information text including 17 characters at maximum by using the arrow buttons. Press **OK**.
5. Press **EXIT** to return to the basic display.

## Using Serial Line

### CTEXT

Use the CTEXT command to enter text to the adjustment information field.

#### Example:

```
>ctext
Adjust. info : (not set) ? HMK15
>
```

### CDATE

Use the CDATE command to enter date to adjustment information field. Set the adjustment date in format YYYY-MM-DD.

#### Example.

```
>cdate
Adjust. date : (not set) ? 2004-05-21
>
```

# CHAPTER 7

## TECHNICAL DATA

This chapter provides the technical data of the product.

### Specifications

#### Performance

##### Relative Humidity

Measurement range	0 ... 100 %RH
Accuracy (including non-linearity, hysteresis and repeatability)	
with HUMICAP <sup>®</sup> 180	for typical applications
HUMICAP <sup>®</sup> 180R	for typical applications
HUMICAP <sup>®</sup> 180C	for applications with chemical purge and/or warmed probe
HUMICAP <sup>®</sup> 180RC	for applications with chemical purge and/or warmed probe
at +15 ... 25 °C	± 1 % RH (0 ... 90 % RH)
at -20 ... +40 °C	± 1.7 % RH (90 ... 100 %RH)
at -40 ... + 180 °C	± (1.0 + 0.008 × reading) % RH
	± (1.5 + 0.015 × reading) % RH
with HUMICAP <sup>®</sup> 180L2	for applications with demanding chemical environment
at -10 ... +40 °C	± (1.0 + 0.01 × reading) % RH
at -40 ... +180 °C	± (1.5 + 0.02 × reading) % RH
Factory calibration uncertainty (+20 °C)	
	±0.6 % RH (0 ... 40 % RH)
	±1.0 % RH (40 ... 97 % RH)
	(Defined as ± 2 standard deviation limits. Small variations possible, see also calibration certificate.)

Response time (90 %) for HUMICAP®180, HUMICAP®180C and HUMICAP®180L2 at 20 °C in still air

- 8 s with grid filter
- 20 s with grid + steel netting filter
- 40 s with sintered filter


Response time (90 %) for HUMICAP®180R and HUMICAP®180RC at 20 °C in 0.1 m/s air flow

- 17 s with grid filter
- 50 s with grid + steel netting filter
- 60 s with sintered filter

### Temperature (+ Operating Pressure Ranges)

HMT331	-40 ... +60 °C (-40 ... +140 °F)
HMT333 80 °C	-40 ... +80 °C (-40 ... +176 °F)
HMT333 120 °C	-40 ... +120 °C (-40 ... +248 °F)
HMT334	-70 ... +180 °C (-94 ... +356 °F), 0 ... 10 MPa (0 ... 100 bar)
HMT335 (vapor tight)	-70 ... +180 °C (-94 ... +356 °F)
HMT337 (vapor tight)	-70 ... +180 °C (-94 ... +356 °F)
HMT338	-70 ... +180 °C (-94 ... +356 °F), 0 ... 4 MPa (0 ... 40 bar)

Accuracy at +20 °C (+68 °F) ± 0.2 °C  
 Accuracy over temperature range (see graph below):



**Figure 60 Accuracy over Temperature Range**

Temperature sensor Pt 100 RTD 1/3 Class B IEC 751

### Optional Temperature Probe

Temperature measurement range: -70 ... + 180 °C (-94 ... +356 °F)

Typical accuracy:	0.1 °C (0.18 °F)
Sensor:	Pt100 PRT DIN IEC 751 class 1/4 B
Cable length:	2 m, 5 m, and 10 m
Pressure tight:	up to 7 bar
Probe material:	stainless steel

## Calculated Variables

**Table 27** Calculated Variables (Typical Ranges)

Variable	HMT331 probe	HMT333 probe	HMT334/335/337/338 probes
Dewpoint temperature	-20 ... +60 °C	-20 ... +80 °C	-20 ... +100 °C
Mixing ratio	0 ... 160 g/kg dry air	0 ... 500 g/kg dry air	0 ... 500 g/kg dry air
Absolute humidity	0 ... 160 g/m <sup>3</sup>	0 ... 500 g/m <sup>3</sup>	0 ... 500 g/m <sup>3</sup>
Wet bulb temperature	0 ... 60 °C	0 ... +100 °C	0 ... +100 °C
Enthalpy	-40 ... +1500 kJ/kg	-40 ... +1500 kJ/kg	-40 ... +1500 kJ/kg
Water vapor pressure	0 ... 1000 hPa	0 ... 1000 hPa	0 ... 1000 hPa

## Accuracies of Calculated Variables

Accuracies of the calculated variables depend on the calibration accuracy of the humidity and temperature sensors; here the accuracies are given for  $\pm 2\%$  RH and  $\pm 0.2\text{ °C}$ .

### Accuracy of Dewpoint Temperature °C

Temp.	Relative humidity									
	10	20	30	40	50	60	70	80	90	100
-40	1.86	1.03	0.76	0.63	0.55	0.50	0.46	0.43	—	—
-20	2.18	1.19	0.88	0.72	0.62	0.56	0.51	0.48	—	—
0	2.51	1.37	1.00	0.81	0.70	0.63	0.57	0.53	0.50	0.48
20	2.87	1.56	1.13	0.92	0.79	0.70	0.64	0.59	0.55	0.53
40	3.24	1.76	1.27	1.03	0.88	0.78	0.71	0.65	0.61	0.58
60	3.60	1.96	1.42	1.14	0.97	0.86	0.78	0.72	0.67	0.64
80	4.01	2.18	1.58	1.27	1.08	0.95	0.86	0.79	0.74	0.70
100	4.42	2.41	1.74	1.40	1.19	1.05	0.95	0.87	0.81	0.76
120	4.86	2.66	1.92	1.54	1.31	1.16	1.04	0.96	0.89	0.84
140	5.31	2.91	2.10	1.69	1.44	1.26	1.14	1.05	0.97	0.91
160	5.80	3.18	2.30	1.85	1.57	1.38	1.24	1.14	1.06	0.99

### Accuracy of Mixing Ratio g/kg (Ambient Pressure 1013 mbar)

Temp.	Relative humidity									
	10	20	30	40	50	60	70	80	90	100
-40	0.003	0.003	0.003	0.003	0.003	0.004	0.004	0.004	—	—
-20	0.017	0.018	0.019	0.021	0.022	0.023	0.025	0.026	—	—
0	0.08	0.09	0.09	0.10	0.10	0.11	0.11	0.12	0.13	0.13
20	0.31	0.33	0.35	0.37	0.39	0.41	0.43	0.45	0.47	0.49
40	0.97	1.03	1.10	1.17	1.24	1.31	1.38	1.46	1.54	1.62
60	2.68	2.91	3.16	3.43	3.72	4.04	4.38	4.75	5.15	5.58
80	6.73	7.73	8.92	10.34	12.05	14.14	16.71	19.92	24.01	29.29
100	16.26	21.34	28.89	40.75	60.86	98.85	183.66	438.56	—	—
120	40.83	74.66	172.36	—	—	—	—	—	—	—

### Accuracy of Wet Bulb Temperature °C


Temp.	Relative humidity									
	10	20	30	40	50	60	70	80	90	100
-40	0.20	0.20	0.20	0.20	0.20	0.20	0.20	0.20	—	—
-20	0.21	0.21	0.22	0.22	0.22	0.22	0.23	0.23	—	—
0	0.27	0.28	0.28	0.29	0.29	0.29	0.30	0.30	0.31	0.31
20	0.45	0.45	0.45	0.44	0.44	0.44	0.43	0.43	0.42	0.42
40	0.84	0.77	0.72	0.67	0.64	0.61	0.58	0.56	0.54	0.52
60	1.45	1.20	1.03	0.91	0.83	0.76	0.71	0.67	0.63	0.60
80	2.23	1.64	1.32	1.13	0.99	0.89	0.82	0.76	0.72	0.68
100	3.06	2.04	1.58	1.31	1.14	1.01	0.92	0.85	0.80	0.75
120	3.85	2.40	1.81	1.48	1.28	1.13	1.03	0.95	0.88	0.83
140	4.57	2.73	2.03	1.65	1.41	1.25	1.13	1.04	0.97	0.91
160	5.25	3.06	2.25	1.82	1.55	1.37	1.24	1.13	1.05	0.99

### Accuracy of Absolute Humidity g/m<sup>3</sup>

Temp.	Relative humidity									
	10	20	30	40	50	60	70	80	90	100
-40	0.004	0.004	0.005	0.005	0.005	0.006	0.006	0.006	—	—
-20	0.023	0.025	0.027	0.029	0.031	0.032	0.034	0.036	—	—
0	0.10	0.11	0.12	0.13	0.13	0.14	0.15	0.15	0.16	0.17
20	0.37	0.39	0.41	0.43	0.45	0.47	0.49	0.51	0.53	0.55
40	1.08	1.13	1.18	1.24	1.29	1.34	1.39	1.44	1.49	1.54
60	2.73	2.84	2.95	3.07	3.18	3.29	3.40	3.52	3.63	3.74
80	6.08	6.30	6.51	6.73	6.95	7.17	7.39	7.61	7.83	8.05
100	12.2	12.6	13.0	13.4	13.8	14.2	14.6	15.0	15.3	15.7
120	22.6	23.3	23.9	24.6	25.2	25.8	26.5	27.1	27.8	28.4
140	39.1	40.0	41.0	42.0	43.0	44.0	45.0	45.9	46.9	47.9
160	63.5	64.9	66.4	67.8	69.2	70.7	72.1	73.5	74.9	76.4

## Dewpoint Temperature (HMT337 Warmed Probe Option)

Find the intersection of the dewpoint temperature curve and the dewpoint difference reading (process temperature-dewpoint temperature) on the x-axis and read the accuracy in dewpoint measurement on the y-axis.



**Figure 61 Accuracy in Dewpoint Measurement**

## Operating Environment

Operating temperature range	
for humidity measurement	-70 ... +180 °C (-94 ... +356 °F) see probe specifications
for transmitter body electronics	-40 ... +60 °C (40 ... +140 °F)
with display	0 ... +60 °C (+32 ... +140 °F)
Storage temperature	-55 ... +80 °C (-67 ... +176 °F)
Electromagnetic compatibility	EN61326-1:1997+ Am1:1998 + Am2:2001 Industrial environment

## Inputs and Outputs

Operating voltage with optional power supply module	10 ... 35 VDC, 24 VAC 100 ... 240 VAC, 50/60 Hz
Start-up time after power-up	3 s
Power consumption @ 20 °C (U <sub>in</sub> 24VDC)	
RS-232	max 25 mA
U <sub>out</sub> 2 × 0 ... 1V / 0 ... 5V / 0 ... 10V	max 25 mA
I <sub>out</sub> 2 × 0 ... 20 mA	max 60 mA
display and backlight	+ 20 mA
during sensor purge	+ 110 mA max
Analog outputs (2 standard, 3rd optional)	
current output	0 ... 20 mA, 4 ... 20 mA
voltage output	0 ... 1 V, 0 ... 5 V, 0 ... 10 V
Accuracy of analog outputs at 20 °C	± 0.05 % full scale
Temperature dependence of the analog outputs	± 0.005 %/°C full scale
External loads	
current outputs	RL < 500 ohm
0 ... 1V output	RL > 2 kohm
0 ... 5V and 0 ... 10V outputs	RL > 10 kohm
Max wire size	0.5 mm <sup>2</sup> (AWG 20) stranded wires recommended
Digital outputs	RS-232, RS-485 (optional)
Relay outputs (optional)	0.5 A, 250 VAC, SPDT
Display (optional)	LCD with backlight, graphic trend display
Menu languages	English, French, Spanish, German, Japanese, Russian, Swedish, Finnish, Chinese.

## Mechanics

Cable bushing	M20x1.5 for cable diameter 8 ... 11mm/0.31..0.43"
Conduit fitting	1/2"NPT
User cable connector (optional)	M12 series 8- pin (male)
option 1	with plug (female) with 5 m / 16.4 ft black cable
option 2	with plug (female) with screw terminals
Probe cable diameter	
HMT333 80°C	6.0 mm
Other probes	5.5 mm
Probe cable lengths	2 m, 5 m or 10 m
Housing material	G-AISI 10 Mg (DIN 1725)
Housing classification	IP 65 (NEMA 4)

## Transmitter Weight

**Table 28 Transmitter Weight (in kg/lb)**

Probe Type	Probe Cable Length		
	2 m	5 m	10 m
HMT333	1.1/2.4	1.2/2.6	1.5/3.3
HMT334	1.4/3.1	1.6/3.5	1.9/4.2
HMT335	1.3/2.9	1.4/3.1	1.7/3.7
HMT337	1.2/2.6	1.3/2.9	1.5/3.3
HMT338 178 mm	1.3/2.9	1.5/3.3	1.7/3.7
HMT338 400 mm	1.4/3.1	1.6/3.5	1.9/4.2

## Technical Specifications of Optional Modules

### Power Supply Module

Operating voltage	100 ... 240 VAC 50/60 Hz
Connections	screw terminals for 0.5 ... 2.5 mm <sup>2</sup> wire (AWG 20 ... 14)
Bushing	for 8 ... 11 mm diameter cable
Operating temperature	-40 ... +60 °C (-40 ... +140 °F)
Storage temperature	-40 ... +70°C (-40 ... +158 °F)

### Analog Output Module

Outputs	0 ... 20 mA, 4 ... 20 mA, 0 ... 1 V, 0 ... 5 V, 0 ... 10 V
Operating temperature range	-40 ... +60 °C (-40 ... +140 °F)
Power consumption	
$U_{out}$ 0 ... 1 V	max 30 mA
$U_{out}$ 0 ... 5V/0 ... 10V	max 30 mA
$I_{out}$ 0 ... 20 mA	max 60 mA
External loads	
current outputs	$R_L < 500$ ohms
Max load + cable loop resistance	540 ohms
0 ... 1 V	$R_L > 2000$ ohms
0 ... 5 V and 0 ... 10 V	$R_L > 10\,000$ ohms
Storage temperature range	-55 ... +80 °C (-67 ... +176 °F)
3-pole screw terminal	
Max wire size	1.5 mm <sup>2</sup> (AWG16)

## Relay Module

Operating temperature range	-40 ... +60 °C (-40 ... +140 °F)
Operating pressure range	500 ... 1300 mmHg
Power consumption @24 V	max 30 mA
Contacts SPDT (change over), for example, Contact arrangement Form C	
I <sub>max</sub>	0.5 A 250 VAC
I <sub>max</sub>	0.5 A 30 VDC
Safety standard for the relay component	IEC60950 UL1950
Storage temperature range	-55 ... +80 °C (-67 ... +176 °F)
3-pole screw terminal / relay	
Max wire size	2.5 mm <sup>2</sup> (AWG14)

## RS-485 Module

Operating temperature range	-40 ... +60 °C (-40 ... +140 °F)
Operating modes	2-wire (1-pair) half duplex 4-wire (2-pair) full duplex
Operating speed max	115.2 kbaud
Bus isolation	300VDC
Power consumption @ 24V	max 50 mA
External loads standard loads	32 RL > 10kohm
Storage temperature range	-55 ... +80 °C (-67 ... +176 °F)
Max wire size	1.5 mm <sup>2</sup> (AWG16)

## Data Logger Module


Operating temperature range	-40 ... +60 °C (-40 ... +140 °F)
Storage temperature range	-55 ... +80 °C (-67 ... +176 °F)
Logged parameters	up to three with trend/min/max values for each
Logging interval	10 s (fixed)
Maximum logging period	4 years 5 months
Logged points	13.7 million points / parameter
Accuracy of the clock	better than ±2 min/year
Battery lifetime	
at -40 ... +30 °C (-40 ... +86 °F)	7 years
at +30 ... +60 °C (+86 ... +140 °F)	5 years

## Options and Accessories

Description	Item code
<b>MODULES</b>	
Relay Module	RELAY-1
Analog Output Module	AOUT-1
Isolated RS485 Module	RS485-1
Power Supply Module	POWER-1
Galvanic Isolation Module	DCDC-1
<b>SENSORS</b>	
HUMICAP180	HUMICAP180
HUMICAP180L2	HUMICAP180L2
HUMICAP180R	HUMICAP180R
PT100 Sensor	10429SP
<b>FILTERS</b>	
PPS Plastic Grid with Stainless Steel Netting	DRW010281SP
PPS Plastic Grid Filter	DRW010276SP
Sintered Filter AISI 316L	HM47280SP
Stainless Steel Filter	HM47453SP
Stainless Steel Filter with Membrane	214848SP
<b>TRANSMITTER MOUNTING ACCESSORIES</b>	
Wall Mounting Kit	214829
Installation Kit for Pole or Pipeline	215108
Rain Shield with Installation Kit	215109
DIN Rail Clips with Installation Plate	215094
Meteorological Installation Kit	HMT330MIK
Panel Mounting Frame	216038
<b>PROBE MOUNTING ACCESSORIES</b>	
<b>HMT334</b>	
Fitting Body M22x1.5	17223SP
Fitting Body NPT1/2	17225SP
<b>HMT335</b>	
Mounting Flange For HMT335	210696
<b>HMT337</b>	
Swagelok for 12mm Probe 3/8" ISO Thread	SWG12ISO38
Swagelok for 12mm Probe 1/2" ISO Thread	SWG12ISO12
Swagelok for 12mm Probe 1/2" NPT Thread	SWG12NPT12
Swagelok for 6mm Probe 1/2" ISO Thread	SWG6ISO12
Swagelok for 6mm Probe 1/8" ISO Thread	SWG6ISO18
Swagelok for 6mm Probe 1/8" NPT Thread	SWG6NPT18
Cable Gland M20x1.5 with Split Seal	HMP247CG
Duct Installation Kit for HMT333 and HMT337	210697
Duct Installation Kit for Temperature	215003

Description	Item code
Probe	
<b>HMT338</b>	
Ball Valve ISO1/2 with Welding Joint	BALLVALVE-1
Fitting Body ISO1/2 Solid Structure	DRW212076SP
Fitting Body NPT1/2 Solid Structure	NPTFITBODASP
Thread Adapter ISO1/2 to NPT1/2	210662SP
Manual Press	HM36854SP
Plug Kit (ISO 1/2)	218773
<b>CONNECTION CABLES</b>	
Serial Interface Cable	19446ZZ
USB-RJ45 Serial Interface Cable	219685
MI70 Connection Cable with RJ45 Connector	211339
HMI41 Connection Cable with RJ45 Connector	25917ZZ
<b>OUTPUT CABLES FOR 8-PIN CONNECTOR</b>	
Connection Cable 5m 8-pin M12 Female, Black	212142
Female Connector 8-pin M12 with Screw Terminals	212416
Male Connector 8-pin M12 with Cable and Adapter	214806SP
<b>CABLE BUSHINGS</b>	
Cable Gland M20x1.5 for 8 ... 11mm Cable	214728SP
Cable Gland M20x1.5 for 11 ... 14mm Cable	214729
Cable Gland M16x1.5 for Wall Mounting Plate Pass-Through	216681SP
Conduit Fitting M20x1.5 for NPT1/2 Conduit	214780SP
Dummy Plug M20x1.5	214672SP
<b>WINDOWS SOFTWARE</b>	
Software Interface Kit	215005
<b>OTHER</b>	
HMK15 Calibration Adapter for 12 mm Probes with >7 mm Sensor Pins	211302SP
HMK15 Calibration Adapter for 12 mm Probes with <3 mm Sensor Pins	218377SP


## Dimensions (in mm)



0506-035


**Figure 62** Transmitter Body Dimensions

## HMT331



**Figure 63 HMT331 Probe Dimensions**

## HMT333



**Figure 64 HMT333 Probe Dimensions**

## HMT334




Figure 65 HMT334 Probe Dimensions

## HMT335




Figure 66 HMT335 Probe Dimensions

The flange is available as an option for the HMT335 probe.

## HMT337




Figure 67 HMT337 Probe Dimensions

## HMT338




Figure 68 HMT338 Probe Dimensions

## Temperature Probe





Figure 69 Optional Temperature Probe Dimensions

## APPENDIX A

# PROBE INSTALLATION KITS AND INSTALLATION EXAMPLES

## Duct Installation Kits (for HMT333/337/335)

Duct installation kit includes a flange, a sealing ring, a supporting bar, a probe attaching part, and screws for attaching the flange to the duct wall. Vaisala order codes: 210697 (for HMT333 and HMT337), 210696 (for HMT335, no supporting bar), and 215003 for temperature probe.



**Figure 70 Duct Mounting Installation Kit**

The following numbers refer to Figure 70 above:


- 1 = Duct wall
- 2 = Flange
- 3 = Sealing ring
- 4 = Supporting bar (not included in the kit for HMT335)
- 5 = Probe attaching part (to be fixed with the supporting bar)
- 6 = Relative humidity probe

### NOTE

When the temperature difference between the duct and the air outside the duct is remarkable, the supporting bar must be installed as deep in the duct as possible. This prevents errors caused by the heat conduction in the bar and cable.

## Duct Installation Kit for Temperature Probe (for HMT337)

Vaisala duct installation kit for the T-probe includes flange, supporting bar, probe attaching part, sealing ring and the fixing screws (4 pcs). Vaisala order code: 215003.



0507-018

**Figure 71 Duct Mounting Installation Kit for T-Probe**


The following numbers refer to Figure 71 above:

- 1 = Duct wall
- 2 = Flange
- 3 = Sealing ring
- 4 = Supporting bar
- 5 = Probe support (to be fixed to the supporting bar)
- 6 = Retainer bushing (to be fixed to the probe support)
- 7 = Temperature probe (to be fixed to the retainer bushing)

# Pressure Tight Swagelok Installation Kits (for HMT337)

## RH Probe Installation

Swagelok installation kit for the relative humidity probe includes Swagelok connector with ISO3/8" or NPT1/2" thread. Vaisala order codes: SWG12ISO38 or SWG12NPT12.




**Figure 72 Swagelok Installation Kit for RH-probe**

The following numbers refer to Figure 72 above:

- 1 = Relative humidity probe
- 2 = Duct connector
- 3 = ISO3/8" or NPT1/2" thread
- 4 = Swagelok connector
- 5 = Ferrules

## Temperature Probe Installation

Swagelok installation kit for T-probe includes Swagelok connector with either ISO1/8" or NPT1/8" thread. Vaisala order codes: SWG6ISO18 or SWG6NPT18.



**Figure 73 Swagelok Installation Kit for T-Probe**


The following numbers refer to Figure 76 below:

- 1 = T-probe
- 2 = Duct connector
- 3 = Swagelok connector
- 4 = Ferrules

## Examples of Vapor Tight Installations with Cable Gland

### RH-Probe Installations (for HMT333/337)

Cable gland AGRO is available from Vaisala (order code: HMP247CG.)




0508-026

**Figure 74 Cable Installation with Cable Gland**

The following numbers refer to Figure 74 above:

- 1 = Nut (to be tightened to the body)
- 2 = Seal
- 3 = Body and O-ring



0508-018


**Figure 75 Probe Installation with Cable Gland**

Probe installation with cable gland is not available from Vaisala.

The following numbers refer to Figure 75 above:

- 1 = AGRO 1160.20.145 (T= -40 ... +100 °C) Not available from Vaisala.
- 2 = In pressurized places, use a locking ring (for example: 11× 1 DIN471).

## T- Probe Installations (HMT337)




0508-015

**Figure 76 Vapor Tight Installation**

Vapor Tight Installation is not available from Vaisala.

The following numbers refer to Figure 76 above:

- 1 = Cable gland. For example AGRO 1100.12.91.065 (T= -25 ... +200 °C)
- 2 = In pressurized processes, use a locking ring (example: 6x 0.7 DIN471)



0508-022


**Figure 77 Wall Mounting Installation**

Wall Mounting Installation is not available from Vaisala.

The following numbers refer to Figure 78 below:

- 1 = Cable gland. For example AGRO 1100.12.91.065
- 2 = Compacted PTFE sleeve
- 3 = Silicon glue between the PTFE sleeve and the cable
- 4 = Temperature probe
- 5 = Recommended support to keep the probe in horizontal position

## Example of Climate Chamber Installation



0507-016

**Figure 78 Climate Chamber Installation (not Available from Vaisala)**


The following numbers refer to Figure 79 below

- 1 = PTFE sleeve
- 2 = Cable gland, for example: AGRO 1100.12.91.065
- 3 = Stainless steel cable tie or similar fastener<sup>1</sup>
- 4 = To be sealed (silicone)
- 5 = Temperature probe
- 6 = Relative humidity probe
- 7 = HMP247CG, Cable gland AGRO (available from Vaisala)

**NOTE**

Let the cables hang loosely to prevent condensed water running to the probe.

## Example of Installation Through Roof



0507-015


**Figure 79 Example of Installation through Roof**

The following numbers refer to Figure 79 above:

- 1 = Insulated probe cables
- 2 = Sealings
- 3 = Roof
- 4 = Cable gland for temperature probe (for example: AGRO 1100.12.91.065)
- 5 = Temperature probe
- 6 = Relative humidity probe
- 7 = Cable gland for relative humidity probe (for example: AGRO 1160.20.145)
- 8 = Plastic adapter to protect probes from condensation water coming from the pipe. Diameter slightly smaller than tube diameter.
- 9 = Plastic tube for probe (2 pcs)
- 10 = Stainless steel tube coming through the roof.
- 11 = Two thread bars holding the plastic adapter.
- 12 = Insulated pipe ending.

## Ball Valve Installation Kit for HMT338

The ball valve installation kit (Vaisala order code: BALLVALVE-1) is preferred when connecting the probe to a pressurized process or pipeline. Use the ball valve set or a 1/2" ball valve assembly with a ball hole of  $\varnothing 14$  mm or more. If you install the probe ( $\varnothing 12$  mm) in a process pipe, please note that the nominal size of the pipe must be at least 1 inch (2.54 cm). Use the manual press handle to press the probe into the pressurized ( $< 10$  bar) process or pipeline.



0507-043

**Figure 80** Installing the HMT338 Probe Through a Ball Valve Assembly

The following numbers refer to Figure 80 above:

- 1 = Manual press tool
- 2 = Handle of the ball valve
- 3 = Probe
- 4 = Process chamber or pipeline
- 5 = Groove on the probe indicates the upper adjustment limit
- 6 = Filter
- 7 = Ball of the ball valve
- 8 = Fitting screw

**NOTE**

The probe can be installed in the process through the ball valve assembly provided that the process pressure is less than 10 bars. This way, the process does not have to be shut down when installing or removing the probe. However, if the process is shut down before removing the probe, the process pressure can be max. 20 bars.

**NOTE**

When measuring temperature dependent quantities make sure that the temperature at the measurement point is equal to that of the process, otherwise the moisture reading may be incorrect.

Follow the steps below to install the HMT338 probe through a ball valve assembly. After the installation, the probe should be sitting in the process chamber or pipeline as shown in Figure 80 on page 154.

1. Shut down the process if the process pressure is more than 10 bars. If the pressure is lower there is no need to shut down the process.
2. Close the ball valve.
3. Seal the threads on the fitting body; refer to Figure 26 on page 42.
4. Attach the fitting body to the ball valve and tighten it.
5. Slide the clasp nut of the probe toward the filter, as far as it will go.
6. Insert the probe to the fitting body, and manually tighten the clasp nut to the fitting body.
7. Open the ball valve.
8. Push the probe through the ball valve assembly into the process. If the pressure is high, use the pressing handle that is provided with the probe. If you push the probe hard without using the handle, you may damage the cable.

Note that the probe must be pushed so deep that the filter is completely inside the process flow.


9. Mark the fitting screw and the clasp nut.
10. Tighten the clasp nut with a fork spanner a further 50 ... 60° (ca. 1/6 turn). If you have a suitable torque spanner, tighten the nut to max  $45 \pm 5$  Nm ( $33 \pm 4$  ft-lbs). Refer to Figure 27 on page 42.

**NOTE** Take care not to tighten the clasp nut more than 60° to avoid difficulties when opening it.

If you wish to remove the probe from the process, note that you have to pull the probe out far enough. You cannot close the valve if the groove on the probe body is not visible.

## Meteorological Installation Kit (for HMT337)

The Vaisala meteorological Installation Kit HMT330MIK (Vaisala order code: HMT330MIK) enables the HMT337 to be installed outdoors to obtain reliable measurements for meteorological purposes. For more information, see HMT330MIK brochure and order form.



0610-078

**Figure 81 Meteorological Installation Kit for Outdoor Installation**

## APPENDIX B

# CALCULATION FORMULAS

This Appendix contains the formulas used for the calculated output quantities.

The HMT330 series transmitters measure relative humidity and temperature. From these values dewpoint, mixing ratio, absolute humidity and enthalpy in normal pressure are calculated using the following equations:

Dewpoint:

$$T_d = \frac{T_n}{\frac{m}{\log\left(\frac{P_w}{A}\right)} - 1} \quad (1)$$

$P_w$  is the water vapor pressure. The parameters  $A$ ,  $m$ , and  $T_n$  depend on temperature according to the following table:

t	A	m	Tn
<0 °C *	6.1134	9.7911	273.47
0 ... 50 °C	6.1078	7.5000	237.3
50 ... 100 °C	5.9987	7.3313	229.1
100 ... 150 °C	5.8493	7.2756	225.0
150 ... 180 °C	6.2301	7.3033	230.0

1) Used for frostpoint calculation if the dewpoint is negative

Mixing ratio:

$$x = 621.99 \cdot \frac{P_w}{p - P_w} \quad (2)$$

Absolute humidity:

$$a = 216.68 \cdot \frac{P_w}{T} \quad (3)$$

Enthalpy:

$$h = (T - 273.15) \cdot (1.01 + 0.00189 \cdot x) + 2.5 \cdot x \quad (4)$$

The water vapor saturation pressure  $P_{ws}$  is calculated by using two equations (5 and 6):

$$\Theta = T - \sum_{i=0}^3 C_i T^i \quad (5)$$

where:

$$\begin{aligned} T &= \text{temperature in K} \\ C_i &= \text{coefficients} \\ C_0 &= 0.4931358 \\ C_1 &= -0.46094296 * 10^{-2} \\ C_2 &= 0.13746454 * 10^{-4} \\ C_3 &= -0.12743214 * 10^{-7} \end{aligned}$$

$$\ln P_{ws} = \sum_{i=-1}^3 b_i \Theta^i + b_4 \ln \Theta \quad (6)$$

where:

$$\begin{aligned} b_i &= \text{coefficients} \\ b_{-1} &= -0.58002206 * 10^4 \\ b_0 &= 0.13914993 * 10^1 \end{aligned}$$

where:

$$\begin{aligned}b_1 &= -0.48640239 * 10^{-1} \\b_2 &= 0.41764768 * 10^{-4} \\b_3 &= -0.14452093 * 10^{-7} \\b_4 &= 6.5459673\end{aligned}$$

The water vapor pressure is calculated using:

$$P_w = RH \cdot \frac{P_{ws}}{100} \quad (7)$$

Parts per million by volume is calculated using:

$$ppm_v = 10^6 \cdot \frac{P_w}{(p - P_w)} \quad (8)$$

Symbols:

$$\begin{aligned}T_d &= \text{dewpoint temperature (}^\circ\text{C)} \\P_w &= \text{water vapor pressure (hPa)} \\P_{ws} &= \text{water vapor saturation pressure (hPa)} \\RH &= \text{relative humidity (\%)} \\x &= \text{mixing ratio (g/kg)} \\p &= \text{atmospheric pressure (hPa)} \\A &= \text{absolute humidity (g/m}^3\text{)} \\T &= \text{temperature (K)} \\h &= \text{enthalpy (kJ/kg)}\end{aligned}$$





[www.vaisala.com](http://www.vaisala.com)